SUN2000-(3KTL-10KTL)-M1

User Manual

Issue 28

Date 2025-09-30





Copyright © Huawei Digital Power Technologies Co., Ltd. 2025. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Digital Power Technologies Co., Ltd.

Trademarks and Permissions

HUAWEI and other Huawei trademarks are the property of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei Digital Power Technologies Co., Ltd. and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied. The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Digital Power Technologies Co., Ltd.

Address: Huawei Digital Power Antuoshan Headquarters

Futian, Shenzhen 518043

People's Republic of China

Website: https://digitalpower.huawei.com

About This Document

Overview

This document describes the SUN2000-3KTL-M1, SUN2000-4KTL-M1, SUN2000-5KTL-M1, SUN2000-6KTL-M1, SUN2000-6KTL-M1, SUN2000-10KTL-BEM1 and SUN2000-10KTL-M1 (SUN2000 for short) in terms of their installation, electrical connections, commissioning, maintenance, and troubleshooting. Before installing and operating the SUN2000, ensure that you are familiar with the features, functions, and safety precautions provided in this document.

□ NOTE

The SUN2000-8KTL-M1, SUN2000-10KTL-BEM1 and SUN2000-10KTL-M1 are not applicable to Australia.

Intended Audience

This document is applicable to:

- Installers
- Users

Symbol Conventions

The symbols that may be found in this document are defined as follows:

Symbol	Description	
▲ DANGER	Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.	
⚠ WARNING	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.	
⚠ CAUTION	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.	

Symbol	Description
NOTICE	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results. Notice is used to Addedress practices not related to personal injury.
□ NOTE	Supplements the important information in the main text. NOTE is used to Addedress information not related to personal injury, equipment damage, and environment deterioration.

Change History

Changes between document issues are cumulative. The latest document issue contains all the changes made in earlier issues.

Issue 28 (2025-09-30)

- Changed "Energy Management Assistant" to "SmartAssistant" throughout the document.
- Updated 2.1 Product Introduction.
- Updated 5.8 (Optional) Connecting Signal Cables.
- Updated 5.8.7 Connecting the Grid Scheduling Signal Cable.
- Updated 7.1.7 Resetting the Password for Logging In to the Local Commissioning Screen.
- Updated 7.2.7 Resetting the Password for Logging In to the Local Commissioning Screen.

Issue 27 (2025-08-15)

Updated 10.1 SUN2000 Technical Specifications.

Issue 26 (2025-07-25)

- Updated 2.3.2 Product Nameplate.
- Updated 5.2 Installation Preparation.
- Updated 5.8.2 Connecting the RS485 Communications Cable (Smart Power Sensor).
- Updated 5.7 (Optional) Installing the Smart Dongle and Anti-theft Components.
- Updated 5.8.7 Connecting the Grid Scheduling Signal Cable.
- Updated 10.1 SUN2000 Technical Specifications.

Issue 25 (2025-07-01)

- Updated 2.1 Product Introduction.
- Updated 2.3.2 Product Nameplate.
- Updated 7.1.6 Limit on Power Purchased from Grid.
- Updated 7.2.6 Limit on Power Purchased from Grid.
- Added 7.1.5 Setting the Energy Measurement Mode.
- Added 7.2.5 Setting the Energy Measurement Mode.

Issue 24 (2025-05-08)

Updated 2.1 Product Introduction.

Issue 23 (2025-04-22)

- Updated 5.2 Installation Preparation.
- Added 7.1.6 Limit on Power Purchased from Grid.
- Added 7.2.6 Limit on Power Purchased from Grid.

Issue 22 (2025-01-10)

- Updated 2.1 Product Introduction.
- Updated 5.2 Installation Preparation.
- Updated 5.8 (Optional) Connecting Signal Cables.
- Added 5.8.4 Connecting RS485 Communications Cables (SmartAssistant).
- Added 5.8.5 Connecting RS485 Communications Cables (SmartAssistant and Battery).
- Added 5.8.6 Connecting RS485 Communications Cables (SmartGuard).
- Updated 7 Power-On and Commissioning.
- Updated 10.1 SUN2000 Technical Specifications.
- Updated A Grid Code.
- Added B Connecting to the Inverter on the App.
- Added C Connecting to the SmartAssistant on the App.

Issue 21 (2024-11-01)

Updated 5.8.3 Connecting an RS485 Communications Cable (Between a Power Meter and a Battery).

Issue 20 (2024-10-23)

Updated 5.8.7 Connecting the Grid Scheduling Signal Cable.

Issue 19 (2024-09-06)

Added 7.3.1 DRM (Australia AS4777).

Issue 18 (2024-06-24)

Delete Locating Insulation Resistance Faults.

Issue 17 (2024-01-12)

- Updated 5.2 Installation Preparation.
- Updated 5.8.2 Connecting the RS485 Communications Cable (Smart Power Sensor).
- Updated 8.3 Troubleshooting.
- Updated 10.1 SUN2000 Technical Specifications.
- Updated A Grid Code.

Issue 16 (2023-11-02)

Updated 5.4 Connecting the AC Output Power Cable.

Issue 15 (2023-09-30)

Updated 7 Power-On and Commissioning.

Issue 14 (2023-09-06)

Updated A Grid Code.

Issue 13 (2023-08-23)

Updated E Rapid Shutdown.

Issue 12 (2023-07-30)

- Updated About This Document.
- Updated 2.1 Product Introduction.
- Updated 5.2 Installation Preparation.
- Updated 10.1 SUN2000 Technical Specifications.

Issue 11 (2023-04-07)

- Updated 5.8.9 Connecting the NS Protection Signal Cable.
- Updated A Grid Code.

Issue 10 (2023-02-07)

- Updated 2.1 Product Introduction.
- Updated 5.2 Installation Preparation.
- Updated 5.8.2 Connecting the RS485 Communications Cable (Smart Power Sensor).
- Updated 5.8.9 Connecting the NS Protection Signal Cable.
- Updated 7 Power-On and Commissioning.

Issue 09 (2022-10-10)

- Updated 5.2 Installation Preparation.
- Updated 5.4 Connecting the AC Output Power Cable.

Issue 08 (2022-06-30)

- Updated 5.2 Installation Preparation.
- Updated 7 Power-On and Commissioning.
- Updated 10.1 SUN2000 Technical Specifications.
- Updated A Grid Code.

Issue 07 (2022-03-04)

- Updated 5.8.2 Connecting the RS485 Communications Cable (Smart Power Sensor).
- Updated D Resetting Password.
- Updated E Rapid Shutdown.

Issue 06 (2021-12-20)

- Updated 7 Power-On and Commissioning.
- Updated 10.1 SUN2000 Technical Specifications.

Issue 05 (2021-11-24)

Updated 10.1 SUN2000 Technical Specifications.

Issue 04 (2021-08-10)

- Updated 2.1 Product Introduction.
- Updated 5.5 Installing DC Input Power Cables.
- Updated 5.6 (Optional) Connecting Battery Cables.
- Updated 5.8 (Optional) Connecting Signal Cables.
- Updated 7 Power-On and Commissioning.

Issue 03 (2021-02-01)

- Updated 4.3.2 Space Requirements.
- Updated 5.8.2 Connecting the RS485 Communications Cable (Smart Power Sensor).
- Updated 6.2 SUN2000 power-on.
- Updated 8.3 Troubleshooting.

Issue 02 (2020-11-20)

• Updated 7 Power-On and Commissioning.

Issue 01 (2020-09-30)

This issue is used for first office application (FOA).

Contents

About This Document	i
1 Safety Information	1
1.1 Personal Safety	2
1.2 Electrical Safety	
1.3 Environment Requirements	
1.4 Mechanical Safety	
2 Overview	13
2.1 Product Introduction	13
2.2 Appearance	17
2.3 Label Description	20
2.3.1 Enclosure Labels	20
2.3.2 Product Nameplate	21
2.4 Working Principles	21
2.4.1 Circuit Diagram	21
2.4.2 Working Modes	22
3 Storage	24
4 Installation	25
4.1 Checking Before Installation	25
4.2 Tools	26
4.3 Determining the Installation Position	27
4.3.1 Environment Requirements	27
4.3.2 Space Requirements	28
4.4 Moving the SUN2000	31
4.5 Installing the Mounting Bracket	31
4.5.1 Wall-mounted Installation	32
4.5.2 Support Mounting	34
5 Electrical Connections	38
5.1 Precautions	38
5.2 Installation Preparation	39
5.3 Connecting the PE cable	43
5.4 Connecting the AC Output Power Cable	45

5.5 Installing DC Input Power Cables	49
5.6 (Optional) Connecting Battery Cables	53
5.7 (Optional) Installing the Smart Dongle and Anti-theft Components	55
5.8 (Optional) Connecting Signal Cables	57
5.8.1 Connecting the RS485 Communications Cable (Inverter Cascading)	62
5.8.2 Connecting the RS485 Communications Cable (Smart Power Sensor)	63
5.8.3 Connecting an RS485 Communications Cable (Between a Power Meter and a Battery)	68
5.8.4 Connecting RS485 Communications Cables (SmartAssistant)	69
5.8.5 Connecting RS485 Communications Cables (SmartAssistant and Battery)	70
5.8.6 Connecting RS485 Communications Cables (SmartGuard)	71
5.8.7 Connecting the Grid Scheduling Signal Cable	72
5.8.8 Connecting a Signal Cable to the Smart Backup Box	73
5.8.9 Connecting the NS Protection Signal Cable	75
6 Commissioning	78
6.1 Checking Before Power-On	78
6.2 SUN2000 power-on	79
7 Power-On and Commissioning	86
7.1 Commissioning the Inverter (Smart Dongle Networking)	
7.1.1 Deploying a New Plant	
7.1.2 Setting Common Parameters	
7.1.3 AFCI	
7.1.4 IPS Test (Italy CEI0-21)	
7.1.5 Setting the Energy Measurement Mode	
7.1.6 Limit on Power Purchased from Grid	
7.1.7 Resetting the Password for Logging In to the Local Commissioning Screen	93
7.1.7.1 Resetting the Password After Connecting to the Device WLAN	
7.1.7.2 Resetting the Password After Obtaining the Verification Code and Connecting to the Dev	ice WLAN
7.2 Commissioning the Inverter (SmartAssistant Networking & SmartGuard Networking)	
7.2.1 Deploying a New Plant	96
7.2.2 Setting Common Parameters	96
7.2.3 AFCI	97
7.2.4 IPS Test (Italy CEI0-21)	99
7.2.5 Setting the Energy Measurement Mode	100
7.2.6 Limit on Power Purchased from Grid	101
7.2.7 Resetting the Password for Logging In to the Local Commissioning Screen	102
7.2.7.1 Resetting the Password After Connecting to the Device WLAN	103
7.2.7.2 Resetting the Password After Obtaining the Verification Code and Connecting to the Dev	
7.2 Constant and a National district Constant	
7.3 SmartLogger Networking Scenario	
7.3.1 DRM (Australia AS4777)	104
8 System Maintenance	106

Oser Mariuat	Contents
8.1 SUN2000 Power-Off	106
8.2 Routine Maintenance	
8.3 Troubleshooting	
8.3 Troubleshooting	108
9 Handling the Inverter	109
9.1 Removing the SUN2000	109
9.2 Packing the SUN2000	109
9.3 Disposing of the SUN2000	109
10 Technical Specifications	110
10.1 SUN2000 Technical Specifications	110
10.2 Optimizer Technical Specifications	119
A Grid Code	122
B Connecting to the Inverter on the App	125
C Connecting to the SmartAssistant on the App	128
D Resetting Password	131
E Rapid Shutdown	132
F Acronyms and Abbreviations	133

1 Safety Information

Statement

Before transporting, storing, installing, operating, using, and/or maintaining the equipment, read this document, strictly follow the instructions provided herein, and follow all the safety instructions on the equipment and in this document. In this document, "equipment" refers to the products, software, components, spare parts, and/or services related to this document; "the Company" refers to the manufacturer (producer), seller, and/or service provider of the equipment; "you" refers to the entity that transports, stores, installs, operates, uses, and/or maintains the equipment.

The Danger, Warning, Caution, and Notice statements described in this document do not cover all the safety precautions. You also need to comply with relevant international, national, or regional standards and industry practices. The Company shall not be liable for any consequences that may arise due to violations of safety requirements or safety standards concerning the design, production, and usage of the equipment.

The equipment shall be used in an environment that meets the design specifications. Otherwise, the equipment may be faulty, malfunctioning, or damaged, which is not covered under the warranty. The Company shall not be liable for any property loss, personal injury, or even death caused thereby.

Comply with applicable laws, regulations, standards, and specifications during transportation, storage, installation, operation, use, and maintenance.

Do not perform reverse engineering, decompilation, disassembly, adaptation, implantation, or other derivative operations on the equipment software. Do not study the internal implementation logic of the equipment, obtain the source code of the equipment software, violate intellectual property rights, or disclose any of the performance test results of the equipment software.

The Company shall not be liable for any of the following circumstances or their consequences:

- The equipment is damaged due to force majeure such as earthquakes, floods, volcanic eruptions, debris flows, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, and other extreme weather conditions.
- The equipment is operated beyond the conditions specified in this document.

- The equipment is installed or used in environments that do not comply with international, national, or regional standards.
- The equipment is installed or used by unqualified personnel.
- You fail to follow the operation instructions and safety precautions on the product and in the document.
- You remove or modify the product or modify the software code without authorization.
- You or a third party authorized by you cause the equipment damage during transportation.
- The equipment is damaged due to storage conditions that do not meet the requirements specified in the product document.
- You fail to prepare materials and tools that comply with local laws, regulations, and related standards.
- The equipment is damaged due to your or a third party's negligence, intentional breach, gross negligence, or improper operations, or other reasons not related to the Company.

1.1 Personal Safety

⚠ DANGER

Ensure that power is off during installation. Do not install or remove a cable with power on. Transient contact between the core of the cable and the conductor will generate electric arcs or sparks, which may cause a fire or personal injury.

⚠ DANGER

Non-standard and improper operations on the energized equipment may cause fire, electric shocks, or explosion, resulting in property damage, personal injury, or even death.

⚠ DANGER

Before operations, remove conductive objects such as watches, bracelets, bangles, rings, and necklaces to prevent electric shocks.


DANGER

During operations, use dedicated insulated tools to prevent electric shocks or short circuits. The dielectric withstanding voltage level must comply with local laws, regulations, standards, and specifications.

MARNING

During operations, wear personal protective equipment such as protective clothing, insulated shoes, goggles, safety helmets, and insulated gloves.

Figure 1-1 Personal protective equipment



General Requirements

- Do not stop protective devices. Pay attention to the warnings, cautions, and related precautionary measures in this document and on the equipment.
- If there is a likelihood of personal injury or equipment damage during operations, immediately stop, report the case to the supervisor, and take feasible protective measures.
- Do not power on the equipment before it is installed or confirmed by professionals.
- Do not touch the power supply equipment directly or with conductors such as damp objects. Before touching any conductor surface or terminal, measure the voltage at the contact point to ensure that there is no risk of electric shock.
- Do not touch operating equipment because the enclosure is hot.
- Do not touch a running fan with your hands, components, screws, tools, or boards. Otherwise, personal injury or equipment damage may occur.
- In the case of a fire, immediately leave the building or the equipment area and activate the fire alarm or call emergency services. Do not enter the affected building or equipment area under any circumstances.

Personnel Requirements

- Only professionals and trained personnel are allowed to operate the equipment.
 - Professionals: personnel who are familiar with the working principles and structure of the equipment, trained or experienced in equipment operations and are clear of the sources and degree of various potential hazards in equipment installation, operation, maintenance

- Trained personnel: personnel who are trained in technology and safety, have required experience, are aware of possible hazards on themselves in certain operations, and are able to take protective measures to minimize the hazards on themselves and other people
- Personnel who plan to install or maintain the equipment must receive adequate training, be able to correctly perform all operations, and understand all necessary safety precautions and local relevant standards.
- Only qualified professionals or trained personnel are allowed to install, operate, and maintain the equipment.
- Only qualified professionals are allowed to remove safety facilities and inspect the equipment.
- Personnel who will perform special tasks such as electrical operations, working at heights, and operations of special equipment must possess the required local qualifications.
- Only authorized professionals are allowed to replace the equipment or components (including software).
- Only personnel who need to work on the equipment are allowed to access the equipment.

1.2 Electrical Safety

DANGER

Before connecting cables, ensure that the equipment is intact. Otherwise, electric shocks or fire may occur.

DANGER

Non-standard and improper operations may result in fire or electric shocks.

DANGER

Prevent foreign matter from entering the equipment during operations. Otherwise, equipment short-circuits or damage, load power derating, power failure, or personal injury may occur.

WARNING

For the equipment that needs to be grounded, install the ground cable first when installing the equipment and remove the ground cable last when removing the equipment.

№ WARNING


During the installation of PV strings and the inverter, the positive or negative terminals of PV strings may be short-circuited to ground if the power cables are not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the inverter. The resulting device damage is not covered under any warranty.

CAUTION

Do not route cables near the air intake or exhaust vents of the equipment.

General Requirements

- Follow the procedures described in the document for installation, operation, and maintenance. Do not reconstruct or alter the equipment, add components, or change the installation sequence without permission.
- Obtain approval from the national or local electric utility company before connecting the equipment to the grid.
- Observe the power plant safety regulations, such as the operation and work ticket mechanisms.
- Install temporary fences or warning ropes and hang "No Entry" signs around the operation area to keep unauthorized personnel away from the area.
- Before installing or removing power cables, turn off the switches of the equipment and its upstream and downstream switches.
- Before performing operations on the equipment, check that all tools meet the requirements and record the tools. After the operations are complete, collect all of the tools to prevent them from being left inside the equipment.
- Before installing power cables, check that cable labels are correct and cable terminals are insulated.
- When installing the equipment, use a torque tool of a proper measurement range to tighten the screws. When using a wrench to tighten the screws, ensure that the wrench does not tilt and the torque error does not exceed 10% of the specified value.
- Ensure that bolts are tightened with a torque tool and marked in red and blue after double-check. Installation personnel mark tightened bolts in blue.
 Quality inspection personnel confirm that the bolts are tightened and then mark them in red. (The marks must cross the edges of the bolts.)



- If the equipment has multiple inputs, disconnect all the inputs and wait until the equipment is completely powered off before performing operations on the equipment.
- Before maintaining a downstream electrical or power distribution device, turn off the output switch on the power supply equipment.

- During equipment maintenance, attach "Do not switch on" labels near the
 upstream and downstream switches or circuit breakers as well as warning
 signs to prevent accidental connection. The equipment can be powered on
 only after troubleshooting is complete.
- Do not open equipment panels.
- Check equipment connections periodically, ensuring that all screws are securely tightened.
- Only qualified professionals can replace a damaged cable.
- Do not scrawl, damage, or block any labels or nameplates on the equipment. Promptly replace labels that have worn out.
- Do not use solvents such as water, alcohol, or oil to clean electrical components inside or outside of the equipment.

Grounding

- Ensure that the grounding impedance of the equipment complies with local electrical standards.
- Ensure that the equipment is connected permanently to the protective ground. Before operating the equipment, check its electrical connection to ensure that it is reliably grounded.
- Do not work on the equipment in the absence of a properly installed ground conductor.
- Do not damage the ground conductor.

Cabling Requirements

- When selecting, installing, and routing cables, follow local safety regulations and rules.
- When routing power cables, ensure that there is no coiling or twisting. Do not join or weld power cables. If necessary, use a longer cable.
- Ensure that all cables are properly connected and insulated, and meet specifications.
- Ensure that the slots and holes for routing cables are free from sharp edges, and that the positions where cables are routed through pipes or cable holes are equipped with cushion materials to prevent the cables from being damaged by sharp edges or burrs.
- Ensure that cables of the same type are bound together neatly and straight and that the cable sheath is intact. When routing cables of different types, ensure that they are away from each other without entanglement and overlapping.
- Secure buried cables using cable supports and cable clips. Ensure that the
 cables in the backfill area are in close contact with the ground to prevent
 cable deformation or damage during backfilling.
- If the external conditions (such as the cable layout or ambient temperature) change, verify the cable usage in accordance with the IEC-60364-5-52 or local laws and regulations. For example, check that the current-carrying capacity meets requirements.
- When routing cables, reserve at least 30 mm clearance between the cables and heat-generating components or areas. This prevents deterioration or damage to the cable insulation layer.

1.3 Environment Requirements

DANGER

Do not expose the equipment to flammable or explosive gas or smoke. Do not perform any operation on the equipment in such environments.

DANGER

Do not store any flammable or explosive materials in the equipment area.

DANGER

Do not place the equipment near heat sources or fire sources, such as smoke, candles, heaters, or other heating devices. Overheat may damage the equipment or cause a fire.

MARNING

Install the equipment in an area far away from liquids. Do not install it under areas prone to condensation, such as under water pipes and air exhaust vents, or areas prone to water leakage, such as air conditioner vents, ventilation vents, or feeder windows of the equipment room. Ensure that no liquid enters the equipment to prevent faults or short circuits.

MARNING

To prevent damage or fire due to high temperature, ensure that the ventilation vents or heat dissipation systems are not obstructed or covered by other objects while the equipment is running.

General Requirements

- Store the equipment according to the storage requirements. Equipment damage caused by unqualified storage conditions is not covered under the warranty.
- Keep the installation and operating environments of the equipment within the allowed ranges. Otherwise, its performance and safety will be compromised.
- The operating temperature range provided in the equipment's technical specifications refers to the ambient temperatures in equipment's installation environment.

- Do not install, use, or operate outdoor equipment and cables (including but not limited to moving equipment, operating equipment and cables, inserting connectors to or removing connectors from signal ports connected to outdoor facilities, working at heights, performing outdoor installation, and opening doors) in harsh weather conditions such as lightning, rain, snow, and level 6 or stronger wind.
- Do not install the equipment in an environment with dust, smoke, volatile or corrosive gases, infrared and other radiations, organic solvents, or salty air.
- Do not install the equipment in an environment with conductive metal or magnetic dust.
- Do not install the equipment in an area conducive to the growth of microorganisms such as fungus or mildew.
- Do not install the equipment in an area with strong vibration, noise, or electromagnetic interference.
- Ensure that the site complies with local laws, regulations, and related standards.
- Ensure that the ground in the installation environment is solid, free from spongy or soft soil, and not prone to subsidence. The site must not be located in a low-lying land prone to water or snow accumulation, and the horizontal level of the site must be above the highest water level of that area in history.
- Do not install the equipment in a position that may be submerged in water.
- If the equipment is installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the equipment using cement or gravel (the area shall be greater than or equal to 3 m x 2.5 m).
- Do not install the equipment outdoors in salt-affected areas because it may be corroded. A salt-affected area refers to the region within 500 m of the coast or prone to sea breeze. Regions prone to sea breeze vary with weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).
- Before installation, operation, and maintenance, clean up any water, ice, snow, or other foreign objects on the top of the equipment.
- When installing the equipment, ensure that the installation surface is solid enough to bear the weight of the equipment.
- After installing the equipment, remove the packing materials such as cartons, foam, plastics, and cable ties from the equipment area.

1.4 Mechanical Safety

MARNING

Ensure that all necessary tools are ready and inspected by a professional organization. Do not use tools that have signs of scratches or fail to pass the inspection or whose inspection validity period has expired. Ensure that the tools are secure and not overloaded.

MARNING

Do not drill holes into the equipment. Doing so may affect the sealing performance and electromagnetic containment of the equipment and damage components or cables inside. Metal shavings from drilling may short-circuit boards inside the equipment.

General Requirements

- Repaint any paint scratches caused during equipment transportation or installation in a timely manner. Equipment with scratches must not be exposed for an extended period of time.
- Do not perform operations such as arc welding and cutting on the equipment without evaluation by the Company.
- Do not install other devices on the top of the equipment without evaluation by the Company.
- When performing operations over the top of the equipment, take measures to protect the equipment against damage.
- Use correct tools and operate them in the correct way.

Moving Heavy Objects

Be cautious to prevent injury when moving heavy objects.



< 18 kg (< 40 lbs)



18-32 kg (40-70 lbs)



32-55 kg (70-121 lbs)



55-68 kg (121-150 lbs)



(> 150 lbs) CZ0000110

- If multiple persons need to move a heavy object together, determine the manpower and work division with consideration of height and other conditions to ensure that the weight is equally distributed.
- If two persons or more move a heavy object together, ensure that the object is lifted and landed simultaneously and moved at a uniform pace under the supervision of one person.
- Wear personal protective gears such as protective gloves and shoes when manually moving the equipment.
- To move an object by hand, approach to the object, squat down, and then lift the object gently and stably by the force of the legs instead of your back. Do not lift it suddenly or turn your body around.
- Do not quickly lift a heavy object above your waist. Place the object on a workbench that is half-waist high or any other appropriate place, adjust the positions of your palms, and then lift it.
- Move a heavy object stably with balanced force at an even and low speed. Put
 down the object stably and slowly to prevent any collision or drop from
 scratching the surface of the equipment or damaging the components and
 cables.


- When moving a heavy object, be aware of the workbench, slope, staircase, and slippery places. When moving a heavy object through a door, ensure that the door is wide enough to move the object and avoid bumping or injury.
- When transferring a heavy object, move your feet instead of turning your waist around. When lifting and transferring a heavy object, ensure that your feet point to the target direction of movement.
- When transporting the equipment using a pallet truck or forklift, ensure that
 the tynes are properly positioned so that the equipment does not topple.
 Before moving the equipment, secure it to the pallet truck or forklift using
 ropes. When moving the equipment, assign dedicated personnel to take care
 of it.
- Choose sea, roads in good conditions, or airplanes for transportation. Do not transport the equipment by railway. Avoid tilt or jolt during transportation.

Using Ladders


- Use wooden or insulated ladders when you need to perform live-line working at heights.
- Platform ladders with protective rails are preferred. Single ladders are not recommended.
- Before using a ladder, check that it is intact and confirm its load bearing capacity. Do not overload it.
- Ensure that the ladder is securely positioned and held firm.



- When climbing up the ladder, keep your body stable and your center of gravity between the side rails, and do not overreach to the sides.
- When a step ladder is used, ensure that the pull ropes are secured.
- If a single ladder is used, the recommended angle for the ladder against the floor is 75 degrees, as shown in the following figure. A square can be used to measure the angle.




- If a single ladder is used, ensure that the wider end of the ladder is at the bottom, and take protective measures to prevent the ladder from sliding.
- If a single ladder is used, do not climb higher than the fourth rung of the ladder from the top.
- If you use a single ladder to climb up to a platform, ensure that the ladder is at least 1 m higher than the platform.



Hoisting

- Only trained and qualified personnel are allowed to perform hoisting operations.
- Install temporary warning signs or fences to isolate the hoisting area.
- Ensure that the foundation where hoisting is performed on meets the load-bearing requirements.
- Before hoisting objects, ensure that hoisting tools are firmly secured onto a fixed object or wall that meets the load-bearing requirements.
- During hoisting, do not stand or walk under the crane or the hoisted objects.
- Do not drag steel ropes and hoisting tools or bump the hoisted objects against hard objects during hoisting.
- Ensure that the angle between two hoisting ropes is no more than 90 degrees, as shown in the following figure.



Drilling Holes

- Obtain consent from the customer and contractor before drilling holes.
- Wear protective equipment such as safety goggles and protective gloves when drilling holes.
- To avoid short circuits or other risks, do not drill holes into buried pipes or cables.
- When drilling holes, protect the equipment from shavings. After drilling, clean up any shavings.

2 Overview

2.1 Product Introduction

Functions

The SUN2000 inverter is a three-phase grid-tied PV string inverter that converts the DC power generated by PV strings into AC power and feeds the power into the power grid.

Model

This document covers the following SUN2000 models:

- SUN2000-3KTL-M1
- SUN2000-4KTL-M1
- SUN2000-5KTL-M1
- SUN2000-6KTL-M1
- SUN2000-8KTL-M1
- SUN2000-10KTL-M1
- SUN2000-10KTL-BEM1

The SUN2000-8KTL-M1, SUN2000-10KTL-BEM1 and SUN2000-10KTL-M1 are not applicable to Australia.

Figure 2-1 Model description (using SUN2000-5KTL-M1 as an example)




Table 2-1 Model description

Identifier	Description	Value	
1	Product family name	SUN2000: three-phase grid-tied PV string inverter	
2	Power class	 3K: rated power of 3 kW 4K: rated power of 4 kW 5K: rated power of 5 kW 6K: rated power of 6 kW 8K: rated power of 8 kW 10K: rated power of 10 kW 	
3	Topology	TL: transformerless	
4	Product code	M1: product series with an input voltage level of 1100 V DC	

Networking Application

The SUN2000 applies to residential rooftop grid-tied systems and small-sized ground PV plant grid-tied systems. Typically, a grid-tied system consists of PV strings, grid-tied inverters, AC switches, and power distribution units.

Slave Primary load Load RS485 PV module Smart Power Optimizer Backup SUN2000 Sensor controller Backup ĎΙ Power grid RS485 DI Battery Ripple Control Device RS485&Enable APP Rapid shutdown switch FusionSolar APP 4G Smart Dongle (Internet 4G Management system! WLAN-FE Smart Dongle FusionSolar Router

— Signal cable — Power cable

--- Wireless communication

Figure 2-2 Networking application (dashed boxes indicate optional components)

□ NOTE

- If the built-in Wi-Fi module of the SUN2000 connects to the app, only device commissioning can be performed.
- If inverters are cascaded without any battery, the main inverter model can be SUN2000-(3KTL-10KTL)-M1 Series. The slave inverter model can be SUN2000-(3KTL-10KTL)-M1 Series, SUN2000-(8KTL-20KTL)-M2, SUN2000-(20KTL-40KTL)-M3, SUN2000-(5KTL-20KTL)-M0, SUN2000-50KTL/60KTL/65KTL-M0, SUN2000-29.9KTL/36KTL, or SUN2000-33KTL-A.
- If inverters are cascaded with an ESS, M1/M2/M5/MB0 can be cascaded. Each M1 can
 connect to a maximum of two ESSs, and each MB0 can connect to a maximum of four ESSs.
 In the Smart Dongle networking scenario, a maximum of three inverters and six ESSs can be
 connected.
- For details about SmartAssistant networking, see Residential Smart PV Solution Quick Guide (Three-Phase PV+ESS Scenario + SmartAssistant Networking) or Residential Smart PV Solution User Manual (SmartAssistant Networking and SmartGuard Networking).
- For details about SmartGuard networking, see Residential Smart PV Solution Quick Guide (Three-Phase PV+ESS Scenario + SmartGuard Networking) or Residential Smart PV Solution User Manual (SmartAssistant Networking and SmartGuard Networking).

♠ CAUTION

The off-grid load output port of the Backup Box cannot be directly connected to the power grid. Otherwise, the Backup Box will be shut down due to overload.

- For a PV string connected to an MPPT circuit, the model, orientation, and tilt angle of PV modules in the PV string must be the same.
- The MPPT voltage must be greater than the lower threshold of the full-load MPPT range specified in the inverter technical data sheet. Otherwise, the inverter will be derated, causing the system yield loss.

Compatibility with Third-Party Systems

Huawei inverters are compatible with third-party inverters or third-party energy storage systems (ESSs).

G F G L В C Μ (A) Optimizer (B) PV string (C) DC switch (D) Huawei smart PV (F) AC power distribution (E) AC switch inverter unit (PDU) (G) Load (H) Router (I) FusionSolar Smart PV Management System (SmartPVMS) (J) FusionSolar app (K) SmartAssistant (L) LUNA2000

Figure 2-3 Networking with third-party systems

Supported Power Grid Types

ESS

(M/O) Third-party

inverter or third-party

The SUN2000 supports TN-S, TN-C, TN-C-S, TT, and IT power grids.

(N) Power meter




Figure 2-4 Power grid types

□ NOTE

- When the SUN2000 is used in the TT power grid, the N-to-PE voltage must be less than 30 V.
- When the SUN2000 is used in the IT power grid, set Isolation to Input ungrounded, with TF.

2.2 Appearance

Figure 2-5 Appearance

(1) LED indicator
 (2) Front panel
 (3) Hanging kit
 (4) Mounting bracket
 (5) Heat sink
 (6) Ventilation valve
 (7) Ground screw
 (8) AC output port (AC)
 (9) Communications port (COM)
 (10) Smart Dongle port (GPRS/4G/WLAN-FE)
 (11) Battery terminals (BAT+/BAT-)
 (12) DC input terminals (PV2+/PV2-)
 (13) DC input terminals (PV1+/PV1-)
 (14) DC switch (DC SWITCH)

(15) Hole for the DC switch locking screw

■ NOTE

Two M6 screw holes are reserved on the left and right sides of the SUN2000 for installing the awning.

Table 2-2 Indicator description

Category	Status		Description
Running	LED1	LED2	-
indicator []~ (m) C C C C C C C C C	Steady green	Steady green	The SUN2000 is operating in grid-tied mode.
LEUT LEUZ	Blinking green at long intervals (on for 1s and then off for 1s)	Off	The DC is on and the AC is off.
	Blinking green at long intervals (on for 1s and then off for 1s)	Blinking green at long intervals (on for 1s and then off for 1s)	Both the DC and AC are on, and the SUN2000 is not supplying power to the power grid.
	Off	Blinking green at long intervals (on for 1s and then off for 1s)	The DC is off and the AC is on.
	Steady orange	Steady orange	The SUN2000 is operating in the off-grid mode.

Category	Status			Description
	Blinking orange slowly	Off		The DC is on, and the SUN2000 has no output in the off-grid mode.
	Blinking orange slowly	Blinking orange slowly		The SUN2000 is operating in the overload in backup mode.
	Off	Off		Both the DC and AC are off.
	Blinking red at short intervals (on for 0.2s and then off for 0.2s)	-		DC environment alarm. For example, the input voltage of the PV string is high, the PV string is reversely connected, or the insulation resistance is low.
	-	Blinking red intervals	at short	AC environment alarm. For example, the power grid is undervoltage, overvoltage, overfrequency, or underfrequency.
	Steady red	Steady red		Fault
Communica	LED3		-	
indicator	for 0.2s and then off for 0.2s)		Communication is in progress. (When a mobile phone is connected to the SUN2000, the indicator blinks green at long intervals, indicating that the phone is connected to the SUN2000.)	
				Mobile phone access
	Off			No communication
Device	LED1	LED2	LED3	-
replacement indicator	Steady red	Steady red	Steady red	The SUN2000 hardware is faulty and the SUN2000 needs to be replaced.

2.3 Label Description


2.3.1 Enclosure Labels

Symbol	Name	Description
Danger: High Voltage! 高压危险! Start maintaining the SUN2000 at least 5 minutes after the SUN2000 disconnects from all external power supplies. 逆变器与外部所有电源断开后需要等待至少5分钟,才可以进行维护。	Delay discharge	Residual voltage exists after the SUN2000 is powered off. It takes 5 minutes for the SUN2000 to discharge to the safe voltage.
Warning: High Temperature! 高温危险! Never touch the enclosure of an operating SUN2000. 逆变器工作时严禁触摸外壳。	Burn warning	Do not touch a running SUN2000 because it generates high temperatures on the shell.
Danger. Electrical Hazardl有电危险! Only certified professionals are allowed to install and operate the SUN2000. 仅有资质的专业人员才可进行 逆变器的安装和操作。 High buch current, earth connection essential before connecting supply. 大接触电流!接通电源前须先接地。	Electric shock warning	 High voltage exists after the SUN2000 is powered on. Only qualified and trained electrical technicians are allowed to perform operations on the SUN2000. High touch current exists after the SUN2000 is powered on. Before powering on the SUN2000, ensure that the SUN2000 is properly grounded.
Read instructions carefully before performing any operation on the SUN2000. 对逆变器进行任何操作前,请仔细阅读说明书!	Refer to documentation	Reminds operators to refer to the documents delivered with the SUN2000.
	Grounding label	Indicates the position for connecting the PE cable.

Symbol	Name	Description
Do not disconnect under load! 禁止帶负荷断开连接I	Operation warning	Do not remove the DC input connector or AC output connector when the SUN2000 is running.
(1P)PN/ITEM:XXXXXXXX (32P)Model: SUN2000-XKTL-XX (S)SN:XXXXXXXXXXXXX MADE IN CHINA	SUN2000 serial number	Indicates the serial number.
MAC: xxxxxxxxxxx	SUN2000 MAC address	Indicates the MAC address.
	SUN2000 Wi-Fi login QR code	Scan the QR code to connect to the Huawei SUN2000 Wi-Fi network.

2.3.2 Product Nameplate

The nameplate contains the trademark, product model, important technical specifications, compliance symbols, company name, and place of origin.



2.4 Working Principles

2.4.1 Circuit Diagram

Two PV strings connect to the SUN2000, and their maximum power points are tracked by two maximum power point tracking (MPPT) circuits. The SUN2000 converts DC power into three-phase AC power through an inverter circuit. Surge protection is supported on both the DC and AC sides.




Figure 2-6 SUN2000 conceptual diagram

2.4.2 Working Modes

The inverter can work in Standby, Operating, or Shutdown mode.

Operating Sufficient power Shutdown from PV string mode command or fault and no fault detected. is detected. PV modules receive no sunlight, the The black start battery works in discharge mode, No sunlight, Insufficient power button of the and the battery reaches the from PV string or with a battery, battery is pressed. end-of-discharge capacity. and the AC power DC switch is supply is resumed. turned off. Standby Shutdown mode mode Shutdown command or fault detected. command or fault rectified.

Figure 2-7 Working modes

IS07S00002

Table 2-3 Working mode description

Working Mode	Description	
Standby	The inverter enters Standby mode when the external environmer does not meet the operating requirements. In Standby mode:	
	The inverter continuously performs status check and enters the Operating mode once the operating requirements are met.	
	The inverter enters Shutdown mode after detecting a shutdown command or a fault after startup.	
Operating	In Operating mode:	
	The inverter converts DC power from PV strings into AC power and feeds the power to the power grid.	
	The inverter tracks the maximum power point to maximize the PV string output.	
	If the inverter detects a fault or a shutdown command, it enters the Shutdown mode.	
	The inverter enters Standby mode after detecting that the PV string output power is not suitable for connecting to the power grid for generating power.	
	If the PV modules receive no sunlight, the battery works in discharge mode, and the battery reaches the end-of-discharge capacity, the inverter enters Standby mode.	
Shutdown	In Standby or Operating mode, the inverter enters Shutdown mode after detecting a fault or shutdown command.	
	In Shutdown mode, the inverter enters Standby mode after detecting a startup command or that the fault is rectified.	
	In Shutdown mode, if the black start button of the battery is pressed, the inverter enters Operating mode.	

3 Storage

The following requirements should be met if the SUN2000 is not put into use directly:

- Do not unpack the SUN2000.
- Keep the storage temperature at -40°C to +70°C and the humidity at 5%-95% RH.
- The SUN2000 should be stored in a clean and dry place and be protected from dust and water vapor corrosion.
- A maximum of eight SUN2000s can be stacked. To avoid personal injury or device damage, stack SUN2000s with caution to prevent them from falling over.
- Periodic inspections are required during the storage. Replace the packing materials if necessary.
- If the SUN2000 has been long-term stored, inspections and tests should be conducted by qualified personnel before it is put into use.

4 Installation

4.1 Checking Before Installation

Outer Packing Materials

Before unpacking the inverter, check the outer packing materials for damage, such as holes and cracks, and check the inverter model. If any damage is found or the inverter model is not what you requested, do not unpack the package and contact your supplier as soon as possible.

□ NOTE

You are advised to remove the packing materials within 24 hours before installing the inverter.

Package Contents

NOTICE

• After placing the equipment in the installation position, unpack it with care to prevent scratches. Keep the equipment stable during unpacking.

After unpacking the inverter, check that the contents are intact and complete. If any damage is found or any component is missing, contact your supplier.

■ NOTE

For details about the number of contents, see the *Packing List* in the packing case.

4.2 Tools

Туре	Tool					
Installa tion Tools						
	Hammer drill Drill bit: Ф8 mm and Ф6 mm	Socket wrench set	Torque screwdriver Phillips head: M3	Diagonal pliers		
		200 E		2000in		
	Wire stripper	Removal wrench Model: PV-MS-HZ Open-end Wrench; manufacturer: Staubli	Rubber mallet	Utility knife		
	Cable cutter	Crimping tool Model: PV- CZM-22100/19100; manufacturer: Staubli	Multimeter DC voltage measurement range ≥ 1100 V DC	Vacuum cleaner		
	₫		£			
	Marker	Measuring tape	Bubble or digital level	Cord end terminal crimper		

Туре	Tool					
	Heat shrink tubing	Heat gun	Cable tie	Hydraulic pliers		
PPE						
	Insulated gloves	Protective gloves	Dust mask	Safety shoes		
		-	-	-		
	Safety goggles					

4.3 Determining the Installation Position

4.3.1 Environment Requirements

Basic Requirements

- The SUN2000 is protected to IP65 and can be installed indoors or outdoors.
- Do not install the SUN2000 in a place where personnel are easy to come into contact with its enclosure and heat sinks, because these parts are extremely hot during operation.
- Do not install the SUN2000 in areas with flammable or explosive materials.
- Do not install the SUN2000 at a place within children's reach.
- Do not install the SUN2000 outdoors in salt areas because it will be corroded there and may cause fire. A salt area refers to the region within 500 meters from the coast or prone to sea breeze. The regions prone to sea breeze vary depending on weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).
- The SUN2000 must be installed in a well-ventilated environment to ensure good heat dissipation.
- Recommended: Install the SUN2000 in a sheltered place or a place with an awning.

Mounting Structure Requirements

- The mounting structure where the SUN2000 is installed must be fireproof.
- Do not install the SUN2000 on flammable building materials.
- The SUN2000 is heavy. Ensure that the installation surface is solid enough to bear the weight load.
- In residential areas, do not install the SUN2000 on drywalls or walls made of similar materials which have a weak sound insulation performance because the noise generated by the SUN2000 is noticeable.


4.3.2 Space Requirements

Installation Angle Requirements

The SUN2000 can be wall-mounted or pole-mounted. The installation angle requirements are as follows:

- Install the SUN2000 vertically or at a maximum back tilt of 15 degrees to facilitate heat dissipation.
- Do not install the SUN2000 at forward tilted, excessive back tilted, side tilted, horizontal, or upside down positions.

Figure 4-1 Installation tilts



Installation Space Requirements

 Reserve enough space around the SUN2000 to ensure sufficient space for installation and heat dissipation.





Figure 4-2 Installation space

• When installing multiple SUN2000s, install them in horizontal mode if sufficient space is available and install them in triangle mode if no sufficient space is available. Stacked installation is not recommended.


Figure 4-3 Horizontal installation (recommended)



IS10H00014

Figure 4-4 Staggered installation (recommended)

Figure 4-5 Stacked installation (not recommended)



4.4 Moving the SUN2000

Procedure

Step 1 Two persons are required to move the SUN2000 with one person on both sides. Lift the SUN2000 from the packing case and move it to the specified installation position.

CAUTION

- Move the SUN2000 with care to prevent device damage and personal injury.
- Do not use the wiring terminals and ports at the bottom to support any weight of the SUN2000.
- Place a foam pad or cardboard under the SUN2000 to protect the SUN2000 enclosure from damage.

Figure 4-6 Moving the SUN2000




----End

4.5 Installing the Mounting Bracket

Installation Precautions

Figure 4-7 shows the dimensions of installation holes on the SUN2000.

Figure 4-7 Mounting bracket dimensions



■ NOTE

Two M6 screw holes are reserved on both left and right sides of the enclosure for installing an awning.

4.5.1 Wall-mounted Installation


Procedure

- **Step 1** Determine the positions for drilling holes and mark the positions using a marker.
- **Step 2** Secure the mounting bracket.

□ NOTE

- M6x60 expansion bolts are delivered with the SUN2000. If the length and number of the bolts do not meet installation requirements, prepare M6 stainless steel expansion bolts by yourself.
- The expansion bolts delivered with the inverter are used for solid concrete walls. For other types of walls, prepare bolts by yourself and ensure that the wall meets the load bearing requirements of the inverter.

Figure 4-8 Expansion bolt composition



IS05W00018

(1) Bolt

(2) Nut

(3) Spring washer

- (4) Flat washer
- (5) Expansion sleeve



Avoid drilling holes in the water pipes and cables buried in the wall.

IS10H00003

NOTICE

- To prevent dust inhalation or contact with eyes, wear safety goggles and a dust mask when drilling holes.
- Clean up any dust in and around the holes using a vacuum cleaner and measure the distance between holes. If the holes are inaccurately positioned, drill holes again.
- Level the top of the expansion sleeve with the concrete wall after removing the bolt, spring washer, and flat washer. Otherwise, the mounting bracket will not be securely installed on the concrete wall.
- Loosen the nuts, flat washers, and spring washers of the two expansion bolts below.





Figure 4-9 Installing the mounting bracket

Step 3 (Optional) Install the locking screw for the DC switch.

□ NOTE


- The locking screw for the DC switch is delivered with the SUN2000. According to the Australian standard, the locking screw is used to secure the DC switch to prevent the SUN2000 from being started by mistake.
- For the model used in Australia, perform this step based on the local standards.

Figure 4-10 Installing the locking screw for the DC switch



- **Step 4** Install the SUN2000 onto the mounting bracket.
- **Step 5** Tighten the nut.

Figure 4-11 Installing a SUN2000




Step 6 (Optional) Install an anti-theft lock.

NOTICE

- Prepare an anti-theft lock suitable for the lock hole diameter (Φ8 mm) by yourself. Ensure that the lock can be installed successfully.
- Outdoor waterproof lock is recommended.
- Keep the key to the anti-theft lock properly.

Figure 4-12 Installing an anti-theft lock



----End

4.5.2 Support Mounting

Prerequisites

Prepare M6 stainless steel bolt assemblies (including flat washers, spring washers, and M6 bolts) with appropriate lengths as well as matched flat washers and nuts based on the support specifications.

Procedure

Step 1 Determine the positions for drilling holes using the marking-off plate, and then mark the positions with a marker.






Figure 4-13 Determining hole positions

Step 2 Drill holes using a hammer drill.

You are advised to apply anti-rust paint on the hole positions for protection.





Step 3 Secure the mounting bracket.





Figure 4-15 Securing the mounting bracket

Step 4 (Optional) Install the locking screw for the DC switch.

□ NOTE


- The locking screw for the DC switch is delivered with the SUN2000. According to the Australian standard, the locking screw is used to secure the DC switch to prevent the SUN2000 from being started by mistake.
- For the model used in Australia, perform this step based on the local standards.

Figure 4-16 Installing the locking screw for the DC switch



- **Step 5** Install the inverter on the mounting bracket.
- **Step 6** Tighten the bolt assemblies.

Figure 4-17 Installing a SUN2000




Step 7 (Optional) Install an anti-theft lock.

NOTICE

- Prepare an anti-theft lock suitable for the lock hole diameter (Φ8 mm).
- An outdoor waterproof lock is recommended.
- Keep the key to the anti-theft lock.

Figure 4-18 Installing an anti-theft lock



----End

5 Electrical Connections

5.1 Precautions

DANGER

When exposed to sunlight, the PV arrays supply DC voltage to the inverter. Before connecting cables, ensure that all **DC SWITCH** on the inverter are OFF. Otherwise, the high voltage of the inverter may result in electric shocks.

DANGER

- The site must be equipped with qualified fire fighting facilities, such as fire sand and carbon dioxide fire extinguishers.
- Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

↑ WARNING

- The equipment damage caused by incorrect cable connections is beyond the warranty scope.
- Only certified electrician can perform electrical terminations.
- Operation personnel must wear PPE when connecting cables.
- Before connecting cables to ports, leave enough slack to reduce the tension on the cables and prevent poor cable connections.

CAUTION


• Stay away from the equipment when preparing cables to prevent cable scraps from entering the equipment. Cable scraps may cause sparks and result in personal injury and equipment damage.

□ NOTE

The cable colors shown in the electrical connection diagrams provided in this section are for reference only. Select cables in accordance with local cable specifications (green-and-yellow cables are only used for protective earthing).

5.2 Installation Preparation

Figure 5-1 SUN2000 cable connections (dashed boxes indicate optional components)



NOTICE

If a Smart Dongle is configured, it is recommended that you install it before connecting the signal cable.

Table 5-1 Component description

No.	Component	Description	Source
A	PV module	 A PV string is composed of the PV modules connected in series and can work with an optimizer. The SUN2000 supports the input from two PV strings. 	Prepared by users
В	(Optional) Smart PV optimizer	Supported models: SUN2000-(450W-P, 600W-P, 450W-P2) and MERC-600W- PA0 ⁴ .	Purchased from Huawei
С	(Optional) Battery	The LUNA2000 batteries can be connected to the SUN2000.	Purchased from Huawei
D	(Optional) Smart Dongle	Supported models: • WLAN-FE Smart Dongle: SDongleA-05 • 4G Smart Dongle: SDongleA-03 and SDongleB-06.	Purchased from Huawei
Е	(Optional) SUN2000	Select a proper model as required.	Purchased from Huawei
F	(Optional) SmartLogger	Select a proper model as required.	Purchased from Huawei
G	(Optional) Power meter ¹	Recommended meter models: DTSU666-H, YDS60-C24 ² , DTSU71 and DHSU1079-CT ³	Purchased from Huawei
Н	(Optional) Power grid scheduling device	Select the devices that meet the power grid scheduling requirements.	Provided by the local power grid company
I	(Optional) Rapid shutdown switch	Select a proper model as required.	Prepared by users

No.	Component	Description	Source
J	AC switch	To ensure that the inverter can be safely disconnected from the power grid when an exception occurs, connect an AC switch to the AC side of the inverter. Select an appropriate AC switch in accordance with local industry standards and regulations. Huawei recommends the following switch specifications:	Prepared by users
		Recommended: a three-phase AC circuit breaker with a rated voltage greater than or equal to 380 V AC and a rated current of:	
		• 16 A (SUN2000-3KTL-M1, SUN2000-4KTL-M1, SUN2000-5KTL-M1, and SUN2000-6KTL-M1)	
		• 25 A (SUN2000-8KTL-M1, SUN2000-10KTL-BEM1 and SUN2000-10KTL-M1)	
К	(Optional) Smart Backup Box	Select a proper model as required.	Purchased from Huawei
L	(Optional) SmartAssistan t	An energy management device used in a residential PV system.	Purchased from Huawei
М	(Optional) SmartGuard	The three-phase SmartGuard can be used to switch the inverter between on-grid and off-grid states. Supported models: SmartGuard-63A-T0 and SmartGuard-63A-AUT0	Purchased from Huawei

No.	Component	Description	Source
-----	-----------	-------------	--------

Note 1: For details about meter operations, DTSU666-H 100 A and 250 A Smart Power Sensor User Manual, DTSU71 Smart Power Sensor Quick Guide, DHSU1079-CT Smart Power Sensor Quick Guide, or YDS60-C24 Smart Power Sensor Quick Guide.

Note 2: SUN2000MA V100R001C00SPC150 and later versions can connect to YDS60-C24 power meters.

Note 3: SUN2000MA V100R001C00SPC160 and later versions can connect to DTSU71 and DHSU1079-CT power meters.

Note 4:

- The SUN2000-(450W-P, 600W-P, 450W-P2) and MERC-600W-PA0 cannot be used together for the same inverter.
- If the MERC-600W-PA0 is selected, the optimizers must be configured for all PV modules.

Table 5-2 Cable description

No.	Name	Туре	Recommended Specifications
1	DC input power cable	Common outdoor PV	Conductor cross-
2	(Optional) Battery cable	cable in the industry (Recommended model: PV1-F)	sectional area: 4–6 mm ² • Cable outer diameter: 5.5–9 mm
3	(Optional) Signal cable ^a	Outdoor shielded twisted pair	• Conductor cross- sectional area: 0.2– 1 mm ²
			Cable outer diameter: 4-11 mm
4	AC output power cable ^b	Outdoor copper cable	 Conductor cross-sectional area: 4-6 mm² Cable outer diameter: 10-21 mm
5	PE cable	Single-core outdoor copper-core cable	Conductor cross- sectional area: ≥ 4 mm ²

No.	Name	Туре	Recommended Specifications
			Specific

Note a: When the smart power sensor and battery are connected to the SUN2000 at the same time, use a cable core with a cross-sectional area of 0.2 mm^2 to 0.5 mm^2 .

Note b: The minimum cable diameter depends on the fuse rating on the AC side.

◯ NOTE

- The minimum cable diameter should comply with the local cable standard.
- Factors influencing cable selection are as follows: rated current, type of cable, routing method, ambient temperature, and maximum desired line losses.

5.3 Connecting the PE cable

Important Notes

A DANGER

- Ensure that the PE cable is securely connected. Otherwise, electric shocks may occur.
- Do not connect the N wire to the enclosure as a PE cable. Otherwise, electric shocks may occur.

□ NOTE

- The PE point at the AC output port is used only as a PE equipotential point, not a substitute for the PE point on the enclosure.
- It is recommended that silica gel or paint be applied around the ground terminal after the PE cable is connected.

Supplementary Notes

The SUN2000 has the grounding detection function. This function is used to check whether the SUN2000 is properly grounded before the SUN2000 starts, or check whether the SUN2000 ground cable is disconnected when the SUN2000 is running. This function is used to check whether the SUN2000 is properly grounded under limited conditions. To ensure the safe operation of the SUN2000, properly ground the SUN2000 according to the connection requirements of the ground cable. For some power grid types, if the output side of the SUN2000 is connected to an isolation transformer, ensure that the SUN2000 is properly grounded and set **Isolation** to **Input ungrounded**, **with TF** to enable the SUN2000 to run properly.

 According to IEC 62109, to ensure the safe operation of the SUN2000 in the case of ground cable damage or disconnection, properly connect the ground cable of the SUN2000 and ensure that it meets at least one of the following requirements before the grounding detection function becomes invalid.


- The ground cable is a single-core outdoor copper cable with a conductor cross-sectional area greater than or equal to 10 mm².
- Use cables with the same diameter as the AC output power cable and ground the PE terminal on the AC connector and the ground screw on the chassis.
- In some countries and regions, the SUN2000 must have additional ground cables. Use cables with the same diameter as the AC output power cable and ground the PE terminal on the AC connector and the ground screw on the chassis.

Procedure

Step 1 Crimp OT terminals.

NOTICE

- Avoid scratching the core wire when stripping a cable.
- The cavity formed after the conductor crimp strip of the OT terminal is crimped must wrap the core wires completely. The core wires must contact the OT terminal closely.
- Wrap the wire crimping area with heat shrink tubing or PVC insulation tape. The heat shrink tubing is used as an example.
- When using a heat gun, protect devices from being scorched.



Step 2 Connect the PE cable.

Figure 5-3 Connecting the PE cable

| M6 |
|----End|

5.4 Connecting the AC Output Power Cable

Precautions

A three-phase AC switch needs to be installed on the AC side of the SUN2000. To ensure that the SUN2000 can safely disconnect itself from the power grid when an

exception occurs, select a proper overcurrent protection device in compliance with local power distribution regulations.

MARNING

- Do not connect loads between an inverter and an AC switch that directly connects to the inverter. Otherwise, the switch may trip by mistake.
- If an AC switch is used with specifications beyond local standards, regulations, or the Company's recommendations, the switch may fail to turn off in a timely manner in case of exceptions, causing serious faults.

CAUTION

Each inverter shall be equipped with an AC output switch. Multiple inverters shall not connect to the same AC switch.

The SUN2000 is integrated with a comprehensive residual current monitoring unit. Once detecting that the residual current exceeds the threshold, the SUN2000 immediately disconnects itself from the power grid.


NOTICE


- If the external AC switch can perform earth leakage protection, the rated leakage action current should be greater than or equal to 100 mA.
- If multiple SUN2000s connect to the general residual current device (RCD) through their respective external AC switches, the rated leakage action current of the general RCD should be greater than or equal to the number of SUN2000s multiplied by 100 mA.
- A knife switch cannot be used as an AC switch.


Procedure

Step 1 Connect the AC output power cable to the AC connector.

Figure 5-4 Stripping requirements







IS06I20048

NOTICE

- Ensure that the cable jacket is inside the connector.
- Ensure that the exposed core wire is totally inserted into the cable hole.
- Ensure that AC terminations provide firm and solid electrical connections.
 Failing to do so may cause SUN2000 malfunction and damage to its AC connectors.
- Ensure that the cable is not twisted.

NOTICE

Strip the insulation layers of the AC output power cable by the recommended length (12–16 mm) to ensure that the cable conductors are completely inside the conductor insertion points and no insulation layer is pressed into the conductor insertion points. Otherwise, the device may fail to run properly or be damaged during operation.

Figure 5-5 Three-core cable (L1, L2, and L3)





Figure 5-6 Four-core cable (L1, L2, L3, and PE)




IS10I20003

12-16 mm
12-16 mm
12-16 mm
16-21 mm
12-16 mm
16-21 mm

Figure 5-7 Four-core cable (L1, L2, L3, and N)

IS10I20002

Figure 5-8 Five-core cable (L1, L2, L3, N, and PE)



□ NOTE


The cable colors shown in the figures are for reference only. Select an appropriate cable according to local standards.

Step 2 Connect the AC connector to the AC output port.

NOTICE

Ensure that the AC connector is connected securely.


Figure 5-9 Securing the AC connector



IS10I20005

Step 3 Check the route of the AC output power cable.

Figure 5-10 Cable route



----End

Disconnection

Disconnection can be performed in reverse order.

5.5 Installing DC Input Power Cables

Important Notes

DANGER

- Before connecting the DC input power cable, ensure that the DC voltage is within the safe range (lower than 60 V DC) and that the DC switch on the SUN2000 is OFF. Otherwise, electric shocks may occur.
- When the SUN2000 is operating, it is not allowed to work on the DC input power cables, such as connecting or disconnecting a PV string or a PV module in a PV string. Otherwise, electric shocks may occur.
- If no PV string connects to a DC input terminal of the SUN2000, do not remove the watertight cap from the DC input terminals. Otherwise, the IP rating of the SUN2000 will be affected.

№ WARNING

Ensure that the following conditions are met. Otherwise, the SUN2000 may be damaged, or even fire could happen.


- PV modules connected in series in each PV string are of the same specifications.
- The open-circuit voltage of each PV string must always be 1100 V DC or lower.
- The maximum short-circuit current of each PV string must always be 15 A or lower.
- The polarities of electric connections are correct on the DC input side. The positive and negative terminals of a PV string connect to corresponding positive and negative DC input terminals of the SUN2000.
- If polarity of the DC input power cable is reversed, do not turn off the DC switch immediately or remove positive and negative connectors. Wait until the solar irradiance declines at night and the PV string current reduces to below 0.5 A, and then turn off the DC switch and remove the positive and negative connectors. Correct the PV string polarity before reconnecting the PV string to the SUN2000.

NOTICE

- Since the output of the PV string connected to the SUN2000 cannot be grounded, ensure that the PV module output is well insulated to ground.
- During the installation of PV strings and the SUN2000, the positive or negative terminals of PV strings may be short-circuited to ground if the power cable is not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the SUN2000. The caused device damage is not covered under any warranty.

Terminal Description

Figure 5-11 Terminal



(1) DC input terminal

(2) Battery terminal

PV+
BAT+
PVBAT-

Figure 5-12 Correct wiring terminals

IS10H30010

Procedure

Step 1 Install the DC input power cables.

WARNING

Before inserting the positive and negative connectors into the positive and negative DC input terminals of the SUN2000, ensure that the DC switch is set to OFF.

⚠ CAUTION

Use the positive and negative Staubli MC4 metal terminals and DC connectors supplied with the SUN2000. Using incompatible positive and negative metal terminals and DC connectors may result in serious consequences. The caused device damage is not covered under warranty.

NOTICE

- Cables with high rigidity, such as armored cables, are not recommended as DC input power cables, because poor contact may be caused by the bending of the cables.
- Before assembling DC connectors, label the cable polarities correctly to ensure correct cable connections.
- After crimping the positive and negative metal terminals, pull back the DC input power cables to ensure that they are securely connected.
- Insert the crimped metal terminals of the positive and negative power cables into the appropriate positive and negative connectors. Then pull back the DC input power cables to ensure that they are connected securely.
- If a DC input power cable is reversely connected and the DC switch is turned on, do not operate on the DC switch or the positive/negative connectors immediately. Otherwise, the device may be damaged. The caused device damage is not covered under any warranty. Wait until the solar irradiance declines at night and the PV string current reduces to below 0.5 A, and then turn off the DC switch and remove the positive and negative connectors. Correct the PV string polarity before reconnecting the PV string to the SUN2000.
- During DC input power cabling, leave at least 50 mm of slack. The axial tension on PV connectors must not exceed 80 N. Radial stress or torque must not be generated on PV connectors.

Ⅲ NOTE

- The DC voltage measurement range of the multimeter must be at least 1100 V.
- If the voltage is a negative value, the DC input polarity is incorrect. Correct the polarity.
- If the voltage is greater than 1100 V DC, too many PV modules configured to the same string. Remove some PV modules.
- If the PV string is configured with an optimizer, check the cable polarity by referring to the smart PV optimizer quick guide.




Figure 5-13 Installing DC input power cables

----End


Removing DC Connectors



Before removing the positive and negative connectors, ensure that the DC switch is OFF.

To remove the positive and negative connectors from the SUN2000, insert an open-end wrench into the bayonet and press the wrench with force. Then remove the DC connectors with caution.

Figure 5-14 Removing DC connectors



5.6 (Optional) Connecting Battery Cables

Prerequisites

A DANGER

- Battery short-circuit may cause personal injury. The high transient current generated by a short-circuit may release a surge of energy and cause fire.
- Do not connect or disconnect the battery cables when the SUN2000 is running. Otherwise, electric shocks may occur.
- Before connecting the battery cables, ensure that the DC switch on the SUN2000 and all the switches connecting to the SUN2000 are OFF, and the SUN2000 has no residual electricity. Otherwise, the high voltage of the SUN2000 and battery may result in electric shocks.
- If no battery connects to the SUN2000, do not remove the watertight caps from the battery terminals. Otherwise, the protection level of the SUN2000 will be affected. If a battery connects to the SUN2000, set aside the watertight caps. Reinstall the watertight caps immediately after removing the connectors.

A battery switch can be configured between the SUN2000 and the battery to ensure that the SUN2000 can be safely disconnected from the battery.

WARNING

- Do not connect loads between the SUN2000 and the battery.
- The battery cables should be connected correctly. That is, the positive and negative terminals of the battery connect to the positive and negative battery terminals on the SUN2000 respectively. Otherwise, the SUN2000 may be damaged, or even fire could happen.

↑ WARNING

During the installation of batteries and the SUN2000, the positive or negative terminals of batteries may be short-circuited to ground if the power cable is not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the SUN2000. The caused device damage is not covered under any warranty.

Procedure

Step 1 Assemble the positive and negative connectors by referring to **5.5 Installing DC Input Power Cables**.

⚠ DANGER

- The battery voltage may result in serious injury. Use dedicated insulation tools when connecting cables.
- Ensure that cables are correctly connected between the battery terminal and the battery switch, and between the battery switch and the SUN2000 battery terminal.

NOTICE

Cables with high rigidity, such as armored cables, are not recommended as battery cables, because poor contact may be caused by the bending of the cables.

Step 2 Insert the positive and negative connectors into corresponding battery terminals on the SUN2000.

NOTICE

After the positive and negative connectors snap into place, pull the battery cables back to ensure that they are connected securely.




Figure 5-15 Connecting battery cables

----End

5.7 (Optional) Installing the Smart Dongle and Antitheft Components

Ⅲ NOTE

- If WLAN-FE communication is used, install the WLAN-FE Smart Dongle (SDongleA-05). For details, see **SDongleA-05 Smart Dongle Quick Guide (WLAN-FE)**.
- If 4G communication is used, install the 4G Smart Dongle (SDongleB-06). For details, see **SDongleB-06 Smart Dongle Quick Guide (4G)**.
- If the Smart Dongle is used, you need to install anti-theft components after installing the Smart Dongle.

WLAN-FE Smart Dongle (FE Communication)

You are advised to use a CAT 5E outdoor shielded network cable (outer diameter < 9 mm; internal resistance ≤ 1.5 ohms/10 m) and shielded RJ45 connectors.

Figure 5-16 Installing the WLAN-FE Smart Dongle (FE communication)





Figure 5-17 Installing anti-theft components for the Smart Dongle



4G Smart Dongle (4G Communication)


◯ NOTE

- If your Smart Dongle is not configured with a SIM card, you need to prepare one (dimensions: 25 mm x 15 mm; capacity: ≥ 64 KB).
- When installing the SIM card, determine its installation direction based on the silk screen and arrow on the card slot.
- Press the SIM card in place to lock it. In this case, the SIM card is correctly installed.
- When removing the SIM card, push it inward to eject it.
- When reinstalling the enclosure of the Smart Dongle, ensure that the snap-fits click into place.

6 LED ILO4H10042

Figure 5-18 Installing the 4G Smart Dongle (SDongleB-06)

Figure 5-19 Installing anti-theft components for the Smart Dongle



5.8 (Optional) Connecting Signal Cables

Communications Port Pin Definitions

NOTICE

- When laying out a signal cable, separate it from power cables and keep it away from strong interference sources to prevent communication interruption.
- Ensure that the protection layer of the signal cable is inside the connector, surplus core wires are cut off from the protection layer, the exposed core wires are inserted completely into the holes, and the cable is connected securely.
- Use rubber plugs to fill the cable holes where no cables are routed through the waterproof rubber rings, and tighten the locking caps to the recommended torque.

2 1 3 4 5 8 7 10 11 12 ¢ 13 **†** 14 15 16 U U IS10W00002

Figure 5-20 Pin definitions

□ NOTE

- If the RS485 communications cables of devices, such as the Smart Power Sensor and battery, are connected to the inverter at the same time, RS485A2 (pin 7), RS485B2 (pin 9), and PE (pin 5) are shared.
- When the enabling signal cables of the battery and the rapid shutdown switch signal cables are connected to the inverter at the same time, GND (pin 13) is shared.

Pin	Definiti on	Function	Description	Pin	Definitio n	Function	Description
1	485A1- 1	RS485A, RS485 differential signal+	Used for cascading inverters or connecting to	2	485A1-2	RS485A, RS485 differential signal+	Used for cascading inverters or connecting
3	485B1- 1	RS485B, RS485 differential signal-	the RS485 signal port of the SmartLogger, SmartAssistant , or SmartGuard	4	485B1-2	RS485B, RS485 differential signal–	to the RS485 signal port of the SmartLogger, SmartAssista nt, or SmartGuard
5	PE	Shield layer grounding	-	6	PE	Shield layer grounding	-

Pin	Definiti on	Function	Description	Pin	Definitio n	Function	Description
7	485A2	RS485A, RS485 differential signal+	Connecting to RS485 signal ports of devices such as power meters and batteries	8	DIN1	Digital input signal 1+	Connecting to the dry contact for power grid scheduling or used as the feedback signal port for the Backup Box or SmartGuard
9	485B2	RS485B, RS485 differential signal-		10	DIN2	Digital input signal 2+	Connecting to the dry contact for
11	EN	Enable signal	For the enable signal of the battery	12	DIN3	Digital input signal 3+	power grid scheduling
13	GND	GND	-	14	DIN4	Digital input signal 4+	Connecting to the dry contact for power grid scheduling or the ripple control receiver for load power control
15	DIN5	Rapid shutdown	Used for the rapid shutdown DI signal or connecting to the signal cable of an NS protection device	16	GND	GND of DIN1, DIN2, DIN3, or DIN4	Connecting to GND of DIN1, DIN2, DIN3, or DIN4

Communication Networking Mode

Only one networking mode applies to an inverter.

Smart Dongle networking




Figure 5-21 Smart Dongle networking (the components in the dashed box are optional)

Table 5-3 Usage restrictions

Smart Dongle	Usage Restrictions	Actual Connection	
	Maximum Number of Devices That Can Be Connected to the Smart Dongle	Number of Inverters	Number of Other Devices ^b
4G ^a	10	n ≤ 10	≤ 10-n
	2	n ≤ 2	≤ 2-n
WLAN-FE	10	n ≤ 10	≤ 10-n

Note a: The maximum number of devices that can be connected to a Smart Dongle is written in the label on the outer package.


Note b: If the power meter and battery are connected through the RS485A2 and RS485B2 ports, they are not included as cascaded devices.

Ⅲ NOTE

- A power meter is required for export limitation. Select a power meter based on the site requirements.
- The power meter and the Smart Dongle must be connected to the same inverter.
- If a battery is connected to the system, a maximum of three inverters can be cascaded, any of which can be connected to the battery (the inverter connected to the Smart Dongle must be connected to the battery).
- If the SUN2000-(3KTL-12KTL)-M1 series and SUN2000-(2KTL-6KTL)-L1 inverters are cascaded, a maximum of three inverters can be cascaded.
- In new deployment and capacity expansion scenarios, it is recommended that multiple single-phase inverters or multiple three-phase inverters be connected in parallel.

SmartLogger networking


Figure 5-22 SmartLogger networking (the component in the dashed box is optional)



□ NOTE


- A maximum of 80 devices can connect to a single SmartLogger. You are advised to connect fewer than 30 devices to each RS485 route.
- If the inverter is connected to the SmartLogger, it cannot be connected to the Smart Dongle.
- A power meter is required for export limitation. Select a power meter based on the site requirements.
- To ensure quick responses of the system, you are advised to connect the power meter separately to a COM port.
- SmartAssistant networking

Figure 5-23 SmartAssistant networking (the component in the dashed box is optional)



SmartGuard networking

Figure 5-24 SmartGuard networking (the component in the dashed box is optional)



5.8.1 Connecting the RS485 Communications Cable (Inverter **Cascading**)

Procedure


Step 1 Connect the signal cable to the signal cable connector.

Figure 5-25 Installing the cable 8 D:4-8 mm D:8-11 mm 485A1-1 -485A1-2 485B1-1 485B1-2 4

Step 2 Connect the signal cable connector to the COM port.

IS10I20006

Figure 5-26 Securing the signal cable connector



----End

5.8.2 Connecting the RS485 Communications Cable (Smart Power Sensor)

Cable Connection

The following figures show the cable connections between the inverter and DTSU666-H and YDS60-C24 meters.

MOTE

The cable connections between the DTSU71 and DHSU1079-CT power meters and the inverter are the same as those between the DTSU666-H power meter and the inverter.

Figure 5-27 DTSU666-H three-phase, three-wire cable connection (Smart Dongle networking)

L1 **6** 6 9 ΙA* lΑ IB* YDS60-C24 ΙB IC^ IC IH05N00006

Figure 5-28 YDS60-C24 three-phase, three-wire cable connection (Smart Dongle networking)




Figure 5-29 Three-phase, four-wire connection (Smart Dongle networking)

(1) Shielding layer of the signal cable

■ NOTE

- If the SUN2000-(2KTL-6KTL)-L1 are cascaded with three-phase inverters, they must be connected to the grid in the same phase.
- In new-deployment or capacity expansion scenarios with multiple inverters, you are advised to connect either single-phase or three-phase inverters in parallel.
- For a three-phase three-wire system, you need to set the cable connection mode. Otherwise, the displayed voltage is incorrect.
- Ensure that the baud rates of the DTSU666-H, YDS60-C24, DTSU71 and DHSU1079-CT meters are set to the default values. If they are changed, meters may go offline, generate alarms, or affect the inverter output power.


Table 5-4 Select the cable connection mode

Paramet er	Note
υEF	Select the cable connection mode:
	0: n.34 indicates three-phase four-wire. 1: n.33 indicates three-phase three-wire.

Procedure


Step 1 Connect the signal cable to the signal cable connector.

Figure 5-30 Installing the cable



Step 2 Connect the signal cable to the COM port.

Figure 5-31 Securing the signal cable connector



IS10I20007

5.8.3 Connecting an RS485 Communications Cable (Between a Power Meter and a Battery)

Procedure

Step 1 Connect the signal cable to the signal cable connector.

PE 485A2 485B2 ASSB2 ASS

Figure 5-32 Installing the cable

Step 2 Connect the signal cable connector to the COM port.

COM COM COM

Figure 5-33 Securing the signal cable connector

IS10I20007


IS10I20012

5.8.4 Connecting RS485 Communications Cables (SmartAssistant)

Procedure


Step 1 Connect the signal cable to the signal cable connector.

Figure 5-34 Installing the cable



Step 2 Connect the signal cable connector to the COM port.

Figure 5-35 Securing the signal cable connector




IS10I20007

5.8.5 Connecting RS485 Communications Cables (SmartAssistant and Battery)

Procedure


Step 1 Connect signal cables to the signal cable connector.

Figure 5-36 Installing cables



Step 2 Connect the signal cable connector to the COM port.

Figure 5-37 Securing the signal cable connector




IS10I20007

5.8.6 Connecting RS485 Communications Cables (SmartGuard)

Procedure

Step 1 Connect the signal cable to the signal cable connector.


Figure 5-38 Installing the cable



IS08I20001

Step 2 Connect the signal cable connector to the COM port.

Figure 5-39 Securing the signal cable connector



IS10I2000

5.8.7 Connecting the Grid Scheduling Signal Cable

Cable Connection

- Smart Dongle, SmartAssistant, and SmartGuard networking: The inverter is connected to the ripple control device. **Figure 5-40** shows the cable connections.
- SmartLogger networking: The SmartLogger is connected to the ripple control device. **Figure 5-41** shows the cable connections.

Figure 5-40 Cable connections (Smart Dongle, SmartAssistant, and SmartGuard networking)





Figure 5-41 Cable connections (SmartLogger networking)




- In Smart Dongle networking, connect to the inverter on the app, log in to the local commissioning screen as an installer, choose Power adjustment > Dry contact scheduling settings, and enable Dry contact scheduling.
- In SmartAssistant networking, connect to the SmartAssistant on the app, log in to the local commissioning screen as an installer, choose Power adjustment > Scheduling via DI Port, and enable Scheduling via DI Port.
- In SmartLogger networking, choose Monitoring > Inverter/PCS > Running Param. > Power Adjustment. Enable Remote power schedule for the inverter/Smart PCS. Choose Settings > Power Adjustment > Active Power Control, and set Active Power Control to DI active scheduling.

Procedure


Step 1 Connect the signal cable to the signal cable connector.

Figure 5-42 Installing the cable



Step 2 Connect the signal cable connector to the COM port.

Figure 5-43 Securing the signal cable connector



IS10I20007

----End

5.8.8 Connecting a Signal Cable to the Smart Backup Box

Procedure


Step 1 Connect the signal cable to the signal cable connector.

DIN1

Figure 5-44 Installing the cable

Step 2 Connect the signal cable connector to the COM port.

Figure 5-45 Securing the signal cable connector



IS10I20007


5.8.9 Connecting the NS Protection Signal Cable

Connecting NS Protection Signal Cables to Inverters

□ NOTE

- The NS protection function is applicable to grid code VDE-AR-N-4105, SWITZERLAND-NA/EEA:2020-LV230, FINLAND-EN50549-LV230, or ANRE.
- The NS protection switch is connected to GND (pin 13) at one end and to DIN5 (pin 15) at the other end. The switch is turned off by default. When the switch is turned on, NS protection is triggered. Rapid shutdown and NS protection use the same pins, which are GND (pin 13) and DIN5 (pin 15). Therefore, you can use only one of the functions.
- The NS protection switch connection is the same for a single inverter and for cascaded inverters.
- Log in to the FusionSolar app as an installer, choose Me > Device commissioning, and connect to the WLAN hotspot of the inverter. Log in to the local commissioning system as an installer, choose Settings > Feature parameters > Dry contact function, and set Dry contact function to NS protection.

Figure 5-46 Connecting cascaded inverters to the NS protection switch




Step 1 Connect the signal cables of the cascaded inverters to the signal cable connectors.

8-11 mm 12-14 mm 13-11 mm 13-1

Figure 5-47 Installing cables

Step 2 Connect the signal cable connectors to the COM ports.

Figure 5-48 Securing the signal cable connector



1310120007

----End

Connecting NS Protection Signal Cables to the SmartLogger

◯ NOTE

- The NS protection function is applicable to grid code VDE-AR-N-4105, SWITZERLAND-NA/EEA:2020-LV230, FINLAND-EN50549-LV230, or ANRE.
- The NS protection device is connected to the AI1 port and 12 V power output port on the SmartLogger. The SmartLogger shuts down the inverter over the voltage change detected at the AI1 port. When the NS protection device is disconnected, the AI1 port voltage is 0 V, and the inverter shuts down. When the NS protection device is connected again, the AI1 port voltage is 12 V, and you need to start the inverter manually.




Figure 5-49 Connecting the SmartLogger to the NS protection switch

6 Commissioning

A DANGER

• Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

6.1 Checking Before Power-On

Table 6-1 Checklist

No.	Item	Acceptance Criterion
1	SUN2000 installation	The SUN2000 is installed correctly and securely.
2	Smart Dongle	The Smart Dongle is installed correctly and securely.
3	Cable routing	The cables are routed properly as required by the customer.
4	Cable ties	Cable ties are secured evenly and no burr exists.
5	Reliable grounding	The PE cable is connected correctly and securely.
6	Switch	DC switches and all the switches connecting to the SUN2000 are OFF.
7	Cable connection	The AC output power cable, DC input power cables, battery cable, and signal cable are connected correctly and securely.
8	Unused terminals and ports	Unused terminals and ports are locked by watertight caps.

No.	Item	Acceptance Criterion
9	Installation environment	The installation space is proper, and the installation environment is clean and tidy.

6.2 SUN2000 power-on

Important Notes

NOTICE

Before the equipment is put into operation for the first time, ensure that the parameters are set correctly by professional personnel. Incorrect parameter settings may result in noncompliance with local grid connection requirements and affect the normal operations of the equipment.

NOTICE

Before turning on the AC switch between the SUN2000 and the power grid, check that the AC voltage is within the specified range using a multimeter.

Procedure


- **Step 1** If a battery is connected, turn on the battery switch.
- **Step 2** Turn on the AC switch between the SUN2000 and the power grid.

NOTICE

If the DC is on and the AC is off, the SUN2000 reports a **Grid Failure** alarm. The SUN2000 starts normally only after the fault is automatically rectified.

Step 3 (Optional) Remove the locking screw from the DC switch.

Figure 6-1 Removing the locking screw from a DC switch



Step 4 Turn on the DC switch (if any) between the PV string and the SUN2000.

- **Step 5** Turn on the DC switch at the bottom of the SUN2000.
- **Step 6** Wait for about 1 minute and observe the LED indicators on the SUN2000 to check its running status.

Table 6-2 LED indicator description

Category	Status		Meaning
Running	LED1	LED2	N/A
indication □ □ □ (♠) □ □ □	Steady green	Steady green	The SUN2000 is operating in gridtied mode.
LED1 LED2	Blinking green at long intervals (on for 1s and then off for 1s)	Off	The DC is on and the AC is off.
	Blinking green at long intervals (on for 1s and then off for 1s)	Blinking green at long intervals (on for 1s and then off for 1s)	The DC is on, the AC is on, and the SUN2000 is not exporting power to the power grid.
	Off	Blinking green at long intervals (on for 1s and then off for 1s)	The DC is off and the AC is on.
	Steady orange	Steady orange	The SUN2000 is operating in the off-grid mode.
	Blinking orange slowly	Off	The DC is on, and the SUN2000 has no output in the off-grid mode.
	Blinking orange slowly	Blinking orange slowly	The SUN2000 is operating in the overload in backup mode.
	Off	Off	Both the DC and AC are off.
	Blinking red at short intervals (on for 0.2s and then off for 0.2s)	N/A	There is a DC environmental alarm, such as an alarm indicating that High String Input Voltage, String Reverse Connection, or Low Insulation Resistance.
	N/A	Blinking red at short intervals (on for 0.2s and then off for 0.2s)	There is an AC environmental alarm, such as an alarm indicating Grid Undervoltage, Grid Overvoltage, Grid Overfrequency, or Grid Underfrequency.
	Steady red	Steady red	Fault

Category	Status			Meaning
Communication n indication	LED3	LED3		N/A
	Blinking green at short intervals (on for 0.2s and then off for 0.2s)		als (on for	Communication is in progress. (When a mobile phone is connected to the SUN2000, the indicator first indicates that the phone is connected to the SUN2000): blinks green at long intervals.)
	Blinking green at long intervals (on for 1s and then off for 1s) Off		als (on for 1s	The mobile phone is connected to the SUN2000.
				There is no communication.
Device	LED1	LED2	LED3	N/A
replacement indication	Steady red	Steady red	Steady red	The SUN2000 hardware is faulty. The SUN2000 needs to be replaced.

□ NOTE

If the off-grid load is overloaded, indicators LED1 and LED2 on the inverter blink orange slowly. Reduce the off-grid load power and manually clear the alarm or until the inverter is recovered. The inverter attempts to restart at an interval of 5 minutes. If the inverter fails to restart for three times, the interval changes to 2 hours. If the inverter is standby in off-grid mode, check the inverter alarms and rectify the fault.

Step 7 (Optional) Observe the LED indicator on the Smart Dongle to check its running status.

WLAN-FE Smart Dongle

Figure 6-2 WLAN-FE Smart Dongle




Table 6-3 Indicator description

Indicators	Status	Remarks	Description
-	Off	Normal	The Smart Dongle is not secured or not powered on.
Yellow (blinking green and red simultaneousl y)	Steady on		The Smart Dongle is secured and powered on.
Red	Blinking at short intervals (on for 0.2s and then off for 0.2s)		The parameters for connecting to the router are not set.
Red	Steady on	Abnormal	The Smart Dongle is faulty. Replace the Smart Dongle.
Blinking red and green alternatively	Blinking at long intervals (on for 1s and then off for 1s)	Abnormal	No communication with the SUN2000 - Remove and then insert the Smart Dongle. - Check whether the SUN2000 matches the Smart Dongle. - Connect the Smart Dongle to another SUN2000. Check whether the Smart Dongle is faulty or the USB port of the SUN2000 is faulty.
Green	Blinking at long intervals (on for 0.5s on and then off for 0.5s)	Normal	Connecting to the router.
Green	Steady on		Connected to the management system.
Green	Blinking at short intervals (on for 0.2s and then off for 0.2s)		The SUN2000 communicates with the management system through the Smart Dongle.

4G Smart Dongle

Table 6-4 Indicator description

Indicators	Status	Remarks	Description
-	Off	Normal	The Smart Dongle is not secured or not powered on.
Yellow (blinking green and red simultaneousl y)	Steady on	Normal	The Smart Dongle is secured and powered on.
Green	The blinking interval is 2s. The	Normal	Dialing (lasting for less than 1 minute)
	indicator is on for 0.1s and then off for 1.9s alternately.	Abnormal	If the duration is longer than 1 minute, the 4G parameter settings are incorrect. Reset the parameters.
	Blinking at long intervals (on for 1s and then off for	Normal	The dialup is successful (lasting for less than 30s).
	1s)	Abnormal	If the duration is longer than 30s, the management system parameters are incorrectly set. Reset the parameters.
	Steady on	Normal	Connected to the management system.
	Blinking at short intervals (on for 0.2s and then off for 0.2s)		The SUN2000 communicates with the management system through the Smart Dongle.
Red	Steady on	Abnormal	The Smart Dongle is faulty. Replace the Smart Dongle.

Indicators	Status	Remarks	Description
	Blinking at short intervals (on for 0.2s and then off for 0.2s)		The Smart Dongle has no SIM card or the SIM card is in poor contact. Check whether the SIM card has been installed or is in good contact. If not, install the SIM card or remove and insert the SIM card.
	Blinking at long intervals (on for 1s and then off for 1s)		The Smart Dongle fails to be connected to a management system because the SIM card has no signals, weak signal strength, or no traffic. If the Smart Dongle is reliably connected, check the SIM card signal through the SUN2000 app. If no signal is received or the signal strength is weak, contact the carrier. Check whether the tariff and traffic of the SIM card are normal. If not, recharge the SIM card or buy traffic.

Indicators	Status	Remarks	Description
Blinking red and green alternatively	Blinking at long intervals (on for 1s and then off for 1s)		No communication with the SUN2000 Remove and then insert the Smart Dongle. Check whether the SUN2000 matches the Smart Dongle. Connect the Smart Dongle to another SUN2000. Check whether the Smart Dongle is faulty or the USB port of the SUN2000 is faulty.

Power-On and Commissioning

A DANGER

 Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

7.1 Commissioning the Inverter (Smart Dongle Networking)

NOTICE

- The grid-connection voltage and frequency of an inverter in China Region are set before delivery according to NB/T 32004 or the latest Chinese standard. If the inverter fails to connect to the power grid because the power grid voltage is close to or higher than the voltage required by Chinese laws and regulations, you can select another voltage level based on the voltage at the grid connection point after obtaining permission from the local power operator.
- If the power grid voltage exceeds the upper threshold, the service life of loads on the grid connection side may be affected, or energy yield loss may occur. In this case, the Company will not be liable for any consequences.

7.1.1 Deploying a New Plant

Figure 7-1 Deploying a new plant



No. Task Description 1 Downloading and Download and install the FusionSolar app. installing an app 2 Registering an Register an installer account required for deployment installer account and commissioning. 3 Access the **Setup wizard** screen, scan the QR code to Creating a plant create a plant, commission devices according to the quick setting process, and connect devices to the

Table 7-1 Plant deployment description

For details, see **FusionSolar App Quick Guide**. Scan the QR code of the inverter to create a plant.

Create an owner account that can be used to

remotely monitor and manage devices.

7.1.2 Setting Common Parameters

Creating an

owner account

4

Set common parameters based on the devices connected to the plant.

plant.

Table 7-2 Setting common parameters

Function	Scenario Description	Operation
Grid-tied point control	Many regions impose a limit on the feed-in power of a power generation system. Therefore, a power meter is required to measure the power at the grid connection point to control the output of the inverter in real time, ensuring that the feed-in power meets the power requirement allowed by the power grid.	For details, see section "Parameter Settings" in the Residential Smart PV Solution User Manual (Smart Dongle Networking and Inverter Direct Connection).
Battery parameter setting	If a battery is connected to the system, you need to add the battery and set battery parameters.	

Function	Scenario Description	Operation
Peak shaving	Applies to areas that have peak demand charges. The peak shaving function allows you to lower the peak power drawn from the grid in maximum self-consumption or TOU mode during peak hours, reducing electricity fees.	
Setting the physical layout of optimizers	If optimizers are configured for PV modules, you can view the physical location of each optimizer after creating a physical layout. If a PV module is faulty, you can quickly locate the faulty PV module from the physical layout to rectify the fault. If a PV module without an optimizer is faulty, you need to check the PV modules one by one to locate the faulty one, which is time-consuming and inefficient.	

For details about how to set more parameters, see **FusionSolar App and SUN2000 App Device Commissioning Guide**.

7.1.3 AFCI

Function Description

If PV modules or cables are incorrectly connected or damaged, electric arcs may be generated, which may cause fire. Huawei inverters provide unique arc fault detection in compliance with UL 1699B-2018 to safeguard users' lives and protect their property.

This function is enabled by default. The inverter automatically detects arc faults. To disable this function, log in to the FusionSolar app, choose **Services** > **Device Commissioning**, connect to the inverter WLAN as prompted, log in to the device, choose **Set** > **Feature parameters** on the home screen, and disable **AFCI**.

The AFCI function works only with Huawei optimizers or ordinary PV modules when the inverter is connected to the grid, but does not support third-party optimizers or intelligent PV modules.

Clearing Alarms

The AFCI function involves the **DC arc fault** alarm.

The inverter has the AFCI alarm automatic clearance mechanism. If the alarm is triggered for less than five times within 24 hours, the inverter automatically clears the alarm. If the alarm is triggered for five times or more within 24 hours, the inverter locks for protection. You need to manually clear the alarm on the FusionSolar app or FusionSolar SmartPVMS so that it can work properly. You can manually clear the alarm in either of the following ways:

- Method 1: FusionSolar app
 - a. Connect to the inverter that has generated the AFCI alarm using the app and log in to the local commissioning screen of the device as an installer.
 - b. Tap **Alarm**. On the **Current Alarms** screen, tap **Clear** on the right of the **DC arc fault** alarm to clear the alarm.

Figure 7-2 Clearing the alarm



- Method 2: FusionSolar SmartPVMS
 - Log in to the FusionSolar SmartPVMS using an installer account, choose Maintenance > Alarm Management, select the DC arc fault alarm, and click Clear.

Figure 7-3 Clearing the alarms



b. Log in the FusionSolar SmartPVMS as a plant owner. Click the plant name on the **Home** page to access the plant page, and clear the alarm as prompted.

7.1.4 IPS Test (Italy CEI0-21)


Function Description

The Italy CEI0-21 grid code requires that an inverter implements an IPS test. During the test, the inverter continuously detects the protection thresholds and protection time thresholds of Maximum voltage over 10 min (59.S1), Maximum voltage (59.S2), Minimum voltage (27.S1), Minimum voltage (27.S2), Maximum frequency (81 > S1), Maximum frequency (81 > S2), Minimum frequency (81 < S1), and Minimum frequency (81 < S2).

Procedure

- **Step 1** Perform operations by referring to **Connecting to the Inverter on the App** and choose **Maintenance** > **IPS test** on the home screen.
- **Step 2** Tap **Start** to start the test.

The inverter simultaneously detects eight parameters Maximum voltage over 10 min (59.S1), Maximum voltage (59.S2), Minimum voltage (27.S1), Minimum voltage (27.S2), Maximum frequency (81 > S1), Maximum frequency (81 > S2), Minimum frequency (81 < S1), and Minimum frequency (81 < S2).






Table 7-3 IPS test types

IPS Test Type	Description
Maximum voltage over 10 min (59.S1)	The default overvoltage voltage over 10 min protection threshold is 253 V (1.10 Vn), and the default protection time threshold is 3s.
Maximum voltage (59.S2)	The default overvoltage protection threshold is 264.5 V (1.15 Vn), and the default protection time threshold is 0.2s.
Minimum voltage (27.S1)	The default undervoltage protection threshold is 195.5 V (0.85 Vn), and the default protection time threshold is 1.5s.
Minimum voltage (27.S2)	The default undervoltage protection threshold is 34.5 V (0.15 Vn), and the default protection time threshold is 0.2s.

IPS Test Type	Description
Maximum frequency (81 > S1)	The default overfrequency protection threshold is 50.2 Hz, and the default protection time threshold is 0.1s.
Maximum frequency (81 > S2)	The default overfrequency protection threshold is 51.5 Hz, and the default protection time threshold is 0.1s.
Minimum frequency (81 < S1)	The default underfrequency protection threshold is 49.8 Hz, and the default protection time threshold is 0.1s.
Minimum frequency (81 < S2)	The default underfrequency protection threshold is 47.5 Hz, and the default protection time threshold is 0.1s.

Step 3 After test is complete, **IPS state** is displayed as **Self-test success**. Tap **Historical report** in the upper right corner of the screen to view the **IPS test** report.

----End

7.1.5 Setting the Energy Measurement Mode

Function Description

This function is used to configure different energy measurement modes for different areas. After power meters are installed, you can configure the measurement modes to implement balanced and unbalanced measurement of energy.

Procedure

- 1. **Connect to the inverter on the app** and log in to the local commissioning screen of the device.
- On the home screen, choose Maintenance > Subdevice management > PowerMeter and set Energy Measurement Mode.




Table 7-4 Energy measurement mode

Parameter		Description
Energy Measurement Mode	Balanced Measurement	Default setting. The forward energy and reversing energy are respectively calculated by integrating the sum of power from three phases.
	Unbalanced Measurement	The forward energy and reversing energy are respectively calculated by integrating the power of each phase.

7.1.6 Limit on Power Purchased from Grid

Function

This function is used to control load power purchased from the grid. The power grid company uses the controller to transmit scheduling commands through the DI4 port. When the load power purchased from the grid is too high, it is limited. After the load capacity of the power grid recovers, the limit on the load power is removed.

NOTICE

Before setting this function, ensure that the inverter is correctly connected to the local DSO controller.

The following figure shows the cable connections between the inverter and the local DSO controller.

COM

GROUP DIA

DSO

Figure 7-5 Cable connections

Procedure

- 1. **Connect to the inverter on the app** and log in to the local commissioning screen of the device as an installer.
- 2. Choose **Power adjustment > Dry contact scheduling settings** and enable **Limit on power purchased from grid**.
- 3. Tap Submit.

∩ NOTE

- If Dry contact scheduling has been enabled and the DI4 port has been configured, clear the DI4 port settings before enabling Limit on power purchased from grid.
 After Limit on power purchased from grid is enabled, the DI4 port is used to receive scheduling commands from the DSO and cannot be used for Dry contact scheduling (in this case, the DI4 port is not displayed on the app).
- ESS charge power from grid refers to the maximum charge power of all ESSs in the current network.

7.1.7 Resetting the Password for Logging In to the Local Commissioning Screen

If you forget the password for logging in to the local commissioning screen of the inverter, perform the following steps to reset the password:

Method 1: Connect to the device WLAN, obtain the verification code, and reset the password. For details, see **7.1.7.1 Resetting the Password After Connecting to the Device WLAN**.

Method 2: Log in to the FusionSolar app, obtain the verification code, and connect to the device WLAN to reset the password. For details, see **7.1.7.2 Resetting the Password After Obtaining the Verification Code and Connecting to the Device WLAN**.

NOTICE

You can reset the login password of only one user at a time.

7.1.7.1 Resetting the Password After Connecting to the Device WLAN

- 1. Log in to the FusionSolar app and choose **Services** > **Device Commissioning**.
- 2. Connect to the WLAN of the inverter and access the Log in screen.
- 3. Select the user role whose password needs to be reset and tap **Forgot** password?.
- 4. On the **Forgot Password** screen, tap **Get Code** and switch the network as prompted.
- 5. Enter the FusionSolar login password to obtain the verification code. After obtaining the verification code, tap **OK** and you will be redirected to the **Forgot Password** screen.
- 6. Enter the verification code, tap **OK**, and set a new password on the **Log in** screen as prompted.

After the verification code is verified, set a new password within 10 minutes.

More Guidance

If the message in the following figure is displayed, tap **OK** to return to the device connection screen, reconnect to the device WLAN, access the **Forgot Password** screen again, and enter the verification code.



7.1.7.2 Resetting the Password After Obtaining the Verification Code and Connecting to the Device WLAN

- 1. Log in to the FusionSolar app and select the target plant on the home screen.
- 2. On the **Device** screen, choose **Inverter** > :: > **O&M Authorization** > **Device verification code**.
- 3. On the **Device verification code** screen, tap **Get Code**, and enter the password for logging in to the FusionSolar to obtain a verification code.

- 4. Copy the verification code as prompted and tap **Proceed** to **connect to the WLAN of the inverter**.
- 5. On the **Log in** screen, select the user whose password needs to be reset, tap **Forgot password?**, enter the verification code, and set a new password as prompted.
 - **□** NOTE

After obtaining the verification code, set a new password within 10 minutes.



7.2 Commissioning the Inverter (SmartAssistant Networking & SmartGuard Networking)

NOTICE

- The grid-connection voltage and frequency of an inverter in China Region are set before delivery according to NB/T 32004 or the latest Chinese standard. If the inverter fails to connect to the power grid because the power grid voltage is close to or higher than the voltage required by Chinese laws and regulations, you can select another voltage level based on the voltage at the grid connection point after obtaining permission from the local power operator.
- If the power grid voltage exceeds the upper threshold, the service life of loads on the grid connection side may be affected, or energy yield loss may occur. In this case, the Company will not be liable for any consequences.

7.2.1 Deploying a New Plant

Figure 7-6 Deploying a new plant



Table 7-5 Plant deployment description

No.	Task	Description
1	Downloading and installing an app	Download and install the FusionSolar app.
2	Registering an installer account	Register an installer account required for deployment and commissioning.
3	Creating a plant	Access the Setup wizard screen, scan the QR code to create a plant, commission devices according to the quick setting process, and connect devices to the plant.
4	Creating an owner account	Create an owner account that can be used to remotely monitor and manage devices.

- SmartAssistant networking: For details, see FusionSolar App Quick Guide (SmartAssistant). Scan the QR code of the SmartAssistant to create a plant.
- SmartGuard networking: For details, see FusionSolar App Quick Guide
 (SmartAssistant). Scan the QR code of the SmartGuard or SmartAssistant to
 create a plant.

7.2.2 Setting Common Parameters

Set common parameters based on the devices connected to the plant.

Table 7-6 Setting common parameters

Function	Scenario Description	Operation
Grid-tied point control	Many regions impose a limit on the feed-in power of a power generation system. Therefore, a power meter is required to measure the power at the grid connection point to control the output of the inverter in real time, ensuring that the feed-in power meets the power requirement allowed by the power grid.	For details, see section "Parameter Settings" in the Residential Smart PV Solution User Manual (SmartAssistant Networking and SmartGuard Networking).
Battery parameter setting	If a battery is connected to the system, you need to add the battery and set battery parameters.	
Peak shaving	Applies to areas that have peak demand charges. The peak shaving function allows you to lower the peak power drawn from the grid in maximum self-consumption or TOU mode during peak hours, reducing electricity fees.	
Setting the physical layout of optimizers	If optimizers are configured for PV modules, you can view the physical location of each optimizer after creating a physical layout. If a PV module is faulty, you can quickly locate the faulty PV module from the physical layout to rectify the fault. If a PV module without an optimizer is faulty, you need to check the PV modules one by one to locate the faulty one, which is time-consuming and inefficient.	

For details about how to set more parameters, see **FusionSolar App and SUN2000 App Device Commissioning Guide**.

7.2.3 AFCI

Function Description

If PV modules or cables are incorrectly connected or damaged, electric arcs may be generated, which may cause fire. Huawei inverters provide unique arc fault

detection in compliance with UL 1699B-2018 to safeguard users' lives and protect their property.

This function is enabled by default. The inverter automatically detects arc faults. To disable this function, log in to the FusionSolar app, choose **Services** > **Device Commissioning**, connect to the inverter WLAN as prompted, log in to the device, choose **Set** > **Feature parameters** on the home screen, and disable **AFCI**.

The AFCI function works only with Huawei optimizers or ordinary PV modules when the inverter is connected to the grid, but does not support third-party optimizers or intelligent PV modules.

Clearing Alarms

The AFCI function involves the **DC arc fault** alarm.

The inverter has the AFCI alarm automatic clearance mechanism. If the alarm is triggered for less than five times within 24 hours, the inverter automatically clears the alarm. If the alarm is triggered for five times or more within 24 hours, the inverter locks for protection. You need to manually clear the alarm on the FusionSolar app or FusionSolar SmartPVMS so that it can work properly. You can manually clear the alarm in either of the following ways:

- Method 1: FusionSolar app
 - a. Connect to the inverter that has generated the AFCI alarm using the app and log in to the local commissioning screen of the device as an installer.
 - b. Tap **Alarm**. On the **Current Alarms** screen, tap **Clear** on the right of the **DC arc fault** alarm to clear the alarm.

Figure 7-7 Clearing the alarm



- Method 2: FusionSolar SmartPVMS
 - Log in to the FusionSolar SmartPVMS using an installer account, choose Maintenance > Alarm Management, select the DC arc fault alarm, and click Clear.

Figure 7-8 Clearing the alarms



b. Log in the FusionSolar SmartPVMS as a plant owner. Click the plant name on the **Home** page to access the plant page, and clear the alarm as prompted.

7.2.4 IPS Test (Italy CEI0-21)

Function Description

The Italy CEI0-21 grid code requires that an inverter implements an IPS test. During the test, the inverter continuously detects the protection thresholds and protection time thresholds of Maximum voltage over 10 min (59.S1), Maximum voltage (59.S2), Minimum voltage (27.S1), Minimum voltage (27.S2), Maximum frequency (81 > S1), Maximum frequency (81 > S2), Minimum frequency (81 < S1), and Minimum frequency (81 < S2).

Procedure

- **Step 1** Perform operations by referring to **Connecting to the Inverter on the App** and choose **Maintenance** > **IPS test** on the home screen.
- **Step 2** Tap **Start** to start the test.

The inverter simultaneously detects eight parameters Maximum voltage over 10 min (59.S1), Maximum voltage (59.S2), Minimum voltage (27.S1), Minimum voltage (27.S2), Maximum frequency (81 > S1), Maximum frequency (81 > S2), Minimum frequency (81 < S1), and Minimum frequency (81 < S2).




Figure 7-9 IPS test

Table 7-7 IPS test types

IPS Test Type	Description
Maximum voltage over 10 min (59.S1)	The default overvoltage voltage over 10 min protection threshold is 253 V (1.10 Vn), and the default protection time threshold is 3s.
Maximum voltage (59.S2)	The default overvoltage protection threshold is 264.5 V (1.15 Vn), and the default protection time threshold is 0.2s.
Minimum voltage (27.S1)	The default undervoltage protection threshold is 195.5 V (0.85 Vn), and the default protection time threshold is 1.5s.
Minimum voltage (27.S2)	The default undervoltage protection threshold is 34.5 V (0.15 Vn), and the default protection time threshold is 0.2s.
Maximum frequency (81 > S1)	The default overfrequency protection threshold is 50.2 Hz, and the default protection time threshold is 0.1s.
Maximum frequency (81 > S2)	The default overfrequency protection threshold is 51.5 Hz, and the default protection time threshold is 0.1s.
Minimum frequency (81 < S1)	The default underfrequency protection threshold is 49.8 Hz, and the default protection time threshold is 0.1s.
Minimum frequency (81 < S2)	The default underfrequency protection threshold is 47.5 Hz, and the default protection time threshold is 0.1s.

Step 3 After test is complete, **IPS state** is displayed as **Self-test success**. Tap **Historical report** in the upper right corner of the screen to view the **IPS test** report.

----End

7.2.5 Setting the Energy Measurement Mode

Function Description

This function is used to configure different energy measurement modes for different areas. After power meters are installed, you can configure the measurement modes to implement balanced and unbalanced measurement of energy.

Procedure

- 1. Connect to the SmartAssistant and log in to the local commissioning screen of the device. **See the connection instructions**.
- 2. On the home screen, choose **Settings** > **Set Installation Parameters** and set **Energy Measurement Mode**.




Table 7-8 Energy measurement mode

Parameter		Description
Energy Measurement Mode	Balanced Measurement	Default setting. The forward energy and reversing energy are respectively calculated by integrating the sum of power from three phases.
	Unbalanced Measurement	The forward energy and reversing energy are respectively calculated by integrating the power of each phase.

7.2.6 Limit on Power Purchased from Grid

Function

This function is used to control load power purchased from the grid. The power grid company uses the controller to transmit scheduling commands through the DI4 port. When the load power purchased from the grid is too high, it is limited. After the load capacity of the power grid recovers, the limit on the load power is removed.

NOTICE

Before setting this function, ensure that the inverter is correctly connected to the local DSO controller.

The following figure shows the cable connections between the inverter and the local DSO controller.

COM

GRODIA

DSO

Figure 7-10 Cable connections

Procedure

- 1. **C Connecting to the SmartAssistant on the App** and log in to the local commissioning screen of the device as an installer.
- Choose Power adjustment > Scheduling via DI Port and enable Limit on power purchased from grid.
- 3. Tap Submit.

□ NOTE

- If Dry contact scheduling has been enabled and the DI4 port has been configured, clear the DI4 port settings before enabling Limit on power purchased from grid. After Limit on power purchased from grid is enabled, the DI4 port is used to receive scheduling commands from the DSO and cannot be used for Scheduling via DI Port (in this case, the DI4 port is not displayed on the app).
- ESS charge power from grid and Charge power of charger refer to the maximum charge power of all ESSs and chargers in the current network, respectively.

7.2.7 Resetting the Password for Logging In to the Local Commissioning Screen

If you forget the password for logging in to the local commissioning screen of the inverter, perform the following steps to reset the password:

Method 1: Connect to the device WLAN, obtain the verification code, and reset the password. For details, see **7.2.7.1 Resetting the Password After Connecting to the Device WLAN**.

Method 2: Log in to the FusionSolar app, obtain the verification code, and connect to the device WLAN to reset the password. For details, see **7.2.7.2 Resetting the Password After Obtaining the Verification Code and Connecting to the Device WLAN**.

NOTICE

You can reset the login password of only one user at a time.

7.2.7.1 Resetting the Password After Connecting to the Device WLAN

- 1. Log in to the FusionSolar app and choose **Services** > **Device Commissioning**.
- 2. Connect to the WLAN of the inverter and access the Log in screen.
- 3. Select the user role whose password needs to be reset and tap **Forgot** password?.
- 4. On the **Forgot Password** screen, tap **Get Code** and switch the network as prompted.
- Enter the FusionSolar login password to obtain the verification code. After obtaining the verification code, tap **OK** and you will be redirected to the **Forgot Password** screen.
- 6. Enter the verification code, tap **OK**, and set a new password on the **Log in** screen as prompted.

After the verification code is verified, set a new password within 10 minutes.

More Guidance

If the message in the following figure is displayed, tap **OK** to return to the device connection screen, reconnect to the device WLAN, access the **Forgot Password** screen again, and enter the verification code.



7.2.7.2 Resetting the Password After Obtaining the Verification Code and Connecting to the Device WLAN

- 1. Log in to the FusionSolar app and select the target plant on the home screen.
- 2. On the **Device** screen, choose **Inverter** > :: > **O&M Authorization** > **Device** verification code.
- 3. On the **Device verification code** screen, tap **Get Code**, and enter the password for logging in to the FusionSolar to obtain a verification code.

- 4. Copy the verification code as prompted and tap **Proceed** to **connect to the WLAN of the inverter**.
- 5. On the **Log in** screen, select the user whose password needs to be reset, tap **Forgot password?**, enter the verification code, and set a new password as prompted.

After obtaining the verification code, set a new password within 10 minutes.



7.3 SmartLogger Networking Scenario

See the *PV Plants Connecting to Huawei Hosting Cloud Quick Guide (Inverters + SmartLogger3000 + RS485 Networking)*. You can scan the QR code to obtain it.

Figure 7-11 SmartLogger3000



7.3.1 DRM (Australia AS4777)

Function

According to Australia standards, inverters need to support the function of demand response modes (DRM), and DRM0 is a mandatory requirement.

This function is disabled by default.




Figure 7-12 Wiring diagram for the DRM function

□ NOTE

- The Demand Response Enabling Device (DRED) is a power grid dispatching device.
- Inverters need to connect to the SmartLogger to implement the DRM function.
- When the master inverter connects to the DRED through SmartLogger, log in to the SmartLogger WebUI and choose Settings > DRM and set DRM parameters.
 Alternatively, scan the QR code on the SmartLogger, log in to the FusionSolar app, choose Power Adjustment > DRM on the home screen, and set DRMO Access Port.

Table 7-9 DRM requirements

Mode	SmartLogger Port	Requirement
DRM0	AI2-AI4	 When S0 is turned on, the inverters shut down. When S0 is turned off, the inverters are connected to the power grid.

Setting DRM on the FusionSolar SmartPVMS

- **Step 1** Log in to the FusionSolar SmartPVMS and select a PV plant on the home page.
- **Step 2** Choose **Device**, select the SmartLogger connected to the inverters, choose **Parameter settings > DRM**, and set **DRM0 Access Port**.

----End

8 System Maintenance

Prerequisites

⚠ DANGER

 Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

WARNING

• Before performing maintenance, power off the equipment, follow the instructions on the delayed discharge label, and wait for a period of time as specified to ensure that the equipment is not energized.

8.1 SUN2000 Power-Off

Important Notes

WARNING


- After the system is powered off, the inverter is still energized and hot, which
 may cause electric shocks or burns. Therefore, wait for 5 minutes after poweroff and then put on insulated gloves to operate the inverter.
- Before maintaining the optimizer and PV string, turn off the AC switch and DC switch. Otherwise, electric shocks may occur as the PV string is energized.

Procedure

- **Step 1** Turn off the AC switch between the SUN2000 and the power grid.
- **Step 2** Turn off the DC switch at the bottom of the SUN2000.

Step 3 (Optional) Install the locking screw beside the DC switch.

Figure 8-1 Installing the locking screw for the DC switch



- **Step 4** If there is a DC switch between the inverter and PV string, turn off the DC switch.
- Step 5 (Optional) Turn off the battery switch between the SUN2000 and batteries.

----End

8.2 Routine Maintenance

To ensure that the SUN2000 can operate properly for a long term, you are advised to perform routine maintenance on it as described in this chapter.



Before cleaning the system, connecting cables, and maintaining the grounding reliability, power off the system.

Table 8-1 Maintenance list

Check Detail	Check Method	Maintenance Interval
System cleanliness	Check the heat sink for foreign matter or the overall health of the SUN2000.	Annual or every time an abnormality is detected
System running status	Check the SUN2000 for damage or deformation.	Annual
Electrical connections	 Cables are securely connected. Cables are intact, in particular, the parts touching the metallic surface are not scratched. 	The first inspection is 6 months after the initial commissioning. From then on, the interval can be 6 to 12 months.
Grounding reliability	Check whether the ground terminal and ground cable are securely connected.	Annual
Sealing	Check whether all terminals and ports are properly sealed.	Annual

8.3 Troubleshooting

For details about alarms, see the **Inverter Alarm Reference**.

9 Handling the Inverter

9.1 Removing the SUN2000

NOTICE

Before removing the SUN2000, power off the AC and DC (batteries).

Perform the following operations to remove the SUN2000:

- 1. Disconnect all cables from the SUN2000, including RS485 communications cables, DC input power cables, AC output power cables, and PGND cables.
- 2. Remove the SUN2000 from the mounting bracket.
- 3. Remove the mounting bracket.

9.2 Packing the SUN2000

- If the original packing materials are available, put the SUN2000 inside them and then seal them by using adhesive tape.
- If the original packing materials are not available, put the SUN2000 inside a suitable cardboard box and seal it properly.

9.3 Disposing of the SUN2000

If the SUN2000 service life expires, dispose of it according to the local disposal rules for electrical equipment waste.

10 Technical Specifications

10.1 SUN2000 Technical Specifications

Efficiency

Technical Specification s	SUN2000- 3KTL-M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN2000- 6KTL-M1	SUN20 00-8KT L-M1	SUN200 0-10KT L-M1	SUN2000 -10KTL- BEM1
Maximum efficiency	98.2%	98.3%	98.4%	98.6%	98.6%	98.6%	98.6%
European efficiency	96.7%	97.1%	97.5%	97.7%	98.0%	98.1%	98.1%

Input

Technical Specifications	SUN20 00-3KT L-M1	SUN2000- 4KTL-M1	SUN200 0-5KTL- M1	SUN2000 -6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1		
Maximum input voltage ^a	1100 V								
Maximum input current (per MPPT)	11 A/13.	11 A/13.5 A (Subject to the product nameplate)							
Maximum short-circuit current (per MPPT)	15 A/19.	5 A (Subject t	to the prod	uct namepla	te)				

Technical Specifications	SUN20 00-3KT L-M1	SUN2000- 4KTL-M1	SUN200 0-5KTL- M1	SUN2000 -6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1		
Minimum startup voltage	200 V								
MPPT voltage range ^c	140–980	V							
Full-load MPPT voltage range	140- 850 V DC	160-850 V DC	200-850 V DC	235-850 V DC	315–850 V DC	390-850 V DC	390-850 V DC		
Rated input voltage	600 V								
Maximum number of inputs	2								
Number of MPPTs ^b	2								
Battery normal voltage	600 Vdc								
Battery voltage range	600-1100	600-1100 Vdc							
Battery maximum current	16.7 A	16.7 A							
Battery type	Li-ion								

Note a: The maximum input voltage is the maximum DC input voltage that the SUN2000 can withstand. If the input voltage exceeds this value, the SUN2000 may be damaged.

Note b: The maximum input power of an MPPT circuit is 8.8 kW. If the input power exceeds this value, the inverter may limit the output power of PV modules.

Note c: If the input voltage is beyond the MPPT voltage range, the inverter cannot work properly.

Output (On Grid)

Technical Specification s	SUN2000 -3KTL- M1	SUN2000 -4KTL-M1	SUN2000 -5KTL- M1	SUN2000 -6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1
Rated output power	3000 W	4000 W	5000 W	6000 W	8000 W	10,000 W	10,000 W

Technical Specification s	SUN2000 -3KTL- M1	SUN2000 -4KTL-M1	SUN2000 -5KTL- M1	SUN2000 -6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1		
Maximum apparent power	3300 VA	4400 VA	5500 VA	6600 VA	8800 VA	11,000 VA	10,000 VA		
Maximum active power (cosφ = 1)	3300 W	4400 W	5500 W	6600 W	8800 W	11,000 W	10,000 W		
Rated output voltage	220 V/380	V, 230 V/400	V, 3W+N+P	PE					
Maximum output voltage at long-term operation	See standa	rds about the	e local powe	er grid.					
Rated output current	4.6 A (380 V)/ 4.4 A (400 V)	6.1 A (380 V) /5.8 A (400 V)	7.6 A (380 V)/ 7.3 A (400 V)	9.1 A (380 V)/ 8.7 A (400 V)	12.2 A (380 V) /11.6 A (400 V)	15.2 A (380 V)/ 14.5 A (400 V)	15.2 A (380 V)/ 14.5 A (400 V)		
Maximum output current	5.1 A	6.8 A	8.5 A	10.1 A	13.5 A	16.9 A	16.9 A		
Rated apparent power	3 kVA	4 kVA	5 kVA	6 kVA	8 kVA	10 kVA	10 kVA		
Inrush current	5.1 A	6.8 A	8.5 A	10.1 A	13.5 A	16.9 A	16.9 A		
Max output fault current	15.06 A	20.08 A	25.1 A	30.12 A	40.16 A	50.2 A	50.2 A		
Max output overcurrent protection	31.8 A	31.8 A	31.8 A						
Output voltage frequency	50 Hz/60 Hz								
Power factor	0.8 leading	–0.8 lagging							

Technical Specification s	SUN2000 -3KTL- M1	SUN2000 -4KTL-M1	SUN2000 -5KTL- M1	SUN2000 -6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1
Maximum total harmonic distortion (THD) AC THDi	< 3% unde	r rated cond	itions. Single	e harmonic r	neets the V	DE4105 req	uirements.

Output (Off Grid)

Technical Specification s	SUN2000- 3KTL-M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN20 00-6KT L-M1	SUN200 0-8KTL- M1	SUN200 0-10KT L-M1	SUN2000- 10KTL- BEM1
Rated apparent power	3000 VA	3300 VA					
Maximum apparent power	3300 VA	3630 VA					

Protection

Technical Specification s	SUN2000 -3KTL- M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN200 0-6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1
Overvoltage category	PV II/AC III						
Input DC switch	Supported						
Islanding protection	Supported						
Output overcurrent protection	Supported						
Input reverse connection protection	Supported						
PV string fault detection	Supported						

Technical Specification s	SUN2000 -3KTL- M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN200 0-6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1
DC surge protection	DC commo	on mode: 10 k	κA				
AC surge protection	Common n	node: 5 kA; d	ifferential mo	ode: 5 kA			
Insulation resistance detection	Supported	Supported					
Residual current monitoring (RCMU)	Supported	Supported					
AFCI	Supported	Supported					
PV module safe shutdown, optimizer	Supported	Supported					
PID repair	Supported						
Active anti- islanding method	AFD						
Protection class							
PV and AC port	DVCC	DVCC					
Communicati on port	DVCA						

Display and Communication

Technical Specification s	SUN2000- 3KTL-M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN200 0-6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1
Display	LED and WLAN+app						
RS485	Supported						

Technical Specification s	SUN2000- 3KTL-M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN200 0-6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KTL -M1	SUN2000- 10KTL- BEM1
External expansion communicati on module	Supports WLAN and 4G.						
remote ripple control	Supported						

General Specifications

Technical Specification s	SUN2000- 3KTL-M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN200 0-6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KT L-M1	SUN2000- 10KTL- BEM1
Dimensions (W x H x D, mm)	525 x 470 x	525 x 470 x 166 (including only the rear mounting kit of the SUN2000)					
Weight	17 kg (inclu	ding only the	e rear mount	ing kit of th	e SUN2000)	
Noise	29 dB (A) (t	ypical workii	ng condition)				
Operating temperature	-25°C to +6	0°C (derated	when the te	mperature i	s higher tha	an 45°C)	
Operating humidity	0–100% RH	0–100% RH					
Cooling mode	Natural con	Natural convection					
Maximum operating altitude	4000 m (de	4000 m (derated when the altitude is greater than 3000 m)					
Storage temperature	-40°C to +7	-40°C to +70°C					
Storage humidity	5-95% RH (5–95% RH (non-condensing)					
Input terminal	Staubli MC4						
Output terminal	Waterproof quick-connect terminal						
IP rating	IP65	IP65					
Topology	Non-Isolatio	on					

Technical Specification s	SUN2000- 3KTL-M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN200 0-6KTL- M1	SUN200 0-8KTL- M1	SUN200 0-10KT L-M1	SUN2000- 10KTL- BEM1
Environment al protection requirements	RoHS 6						

Wireless Communication Parameters

Specifications	Inverter Built- in WiFi	WLAN-FE Smart Dongle	4G Smart Dongle
Frequency	2400-2483.5 MHz	SDongleA-05: 2400-2483.5 MHz	 SDongleA-03-EU: Supports LTE-FDD: B1/B3/B7/B8/B20. Supports LTE-TDD: B38/B40. Supports WCDMA/HSDPA/HSUPA/HSPA+: B1/B8. Supports GSM/GPRS/EDGE: 900 MHz/1800 MHz. SDongleB-06-EU (WiFi): 2400-2483.5 MHz SDongleB-06-EU (4G): Supports LTE-FDD: B1/B3/B5/B8. Supports LTE-TDD: B7/B20/B28/B38/B40/B41. Supports GSM/GPRS/EDGE: 900 MHz/1800 MHz.

Specifications	Inverter Built- in WiFi	WLAN-FE Smart Dongle	4G Smart Dongle
Protocol standard	WLAN 802.11b/g/n	SDongleA-05: WLAN 802.11b/g/n	 SDongleA-03-EU: Supports LTE-FDD (with receive diversity): B1/B3/B7/B8/B20/B28. Supports LTE-FDD (with receive diversity): B38/B40/B41. Supports WCDMA: B1/B8. Supports GSM: 900 MHz/1800 MHz. Supports digital audio. SDongleB-06-EU (WiFi): WLAN 802.11b/g/n SDongleB-06-EU (4G): Supports LTE FDD (with receive diversity): B1/B3/B5/B8. Supports LTE-TDD (with receive diversity): B7/B20/B28/B38/B40/B41. Supports GSM: 900 MHz/1800 MHz. Supports digital audio.

Specifications	Inverter Built- in WiFi	WLAN-FE Smart Dongle	4G Smart Dongle
Bandwidth	20 MHz/40 MHz	20 MHz/40 MHz (optional)	LTE features:
	(optional)		Supports a maximum of 3GPP R8 non- CA Cat 4 FDD and TDD.
			Supports 1.4 MHz/3 MHz/5 MHz/10 MHz/15 MHz/20 MHz RF bandwidth.
			Supports MIMO in the downlink.
			 LTE-FDD: maximum downlink rate of 150 Mbit/s and maximum uplink rate of 50 Mbit/s
			LTE-TDD: maximum downlink rate of 130 Mbit/s and maximum uplink rate of 30 Mbit/s
			UMTS features:
			Supports 3GPP R7 HSDPA+, HSDPA, HSUPA, and WCDMA.
			Supports QPSK and 16QAM modulation.
			HSDPA+: maximum downlink rate of 21 Mbit/s
			HSUPA: maximum uplink rate of 5.76 Mbit/s
			WCDMA: maximum downlink rate of 384 kbit/s and maximum uplink rate of 384 kbit/s
			GSM features:
			GPRS:
			Supports GPRS multislot class 12.
			• Coding schemes: CS-1, CS-2, CS-3, and CS-4
			Maximum downlink rate: 85.6 kbit/s; maximum uplink rate: 85.6 kbit/s
			EDGE:
			Supports EDGE multislot class 12.
			 Supports GMSK and 8-PSK modulation and coding schemes.
			Downlink coding format: MCS 1–9
			Uplink coding format: MCS 1–9
			Maximum downlink rate: 236.8 kbit/s; maximum uplink rate: 236.8 kbit/s
			SDongleB-06-EU (WiFi): 20 MHz/40 MHz (optional)

Specifications	Inverter Built- in WiFi	WLAN-FE Smart Dongle	4G Smart Dongle
Maximum transmit power	≤ 20 dBm EIRP	≤ 20 dBm EIRP	 Class 4 (33 dBm±2 dB), EGSM900 frequency band
			 Class 1 (30 dBm±2 dB), DCS1800 frequency band
			 Class E2 (27 dBm±3 dB), EGSM900 8- PSK
			 Class E2 (26 dBm±3 dB), DCS1800 8- PSK
			 Class 3 (24 dBm+1/-3 dB), WCDMA frequency band
			 Class 3 (23 dBm±2 dB), LTE-FDD frequency band
			 Class 3 (23 dBm±2 dB), LTE-TDD frequency band
			SDongleB-06-EU (WiFi): ≤ 20 dBm EIRP

Ⅲ NOTE

The SDongleA-03 will no longer be placed on the market.

10.2 Optimizer Technical Specifications

Efficiency

Technical Specifications	SUN2000-450W-P
Maximum efficiency	99.5%
European weighted efficiency	99.0%

Input

Technical Specifications	SUN2000-450W-P
Rated PV module power	450 W
Maximum PV module power	472.5 W

Technical Specifications	SUN2000-450W-P
Maximum input voltage	80 V
MPPT voltage range	8–80 V
Maximum short- circuit current	13 A
Overvoltage level	II

Output

Technical Specifications	SUN2000-450W-P
Rated output power	450 W
Output voltage	4-80 V
Maximum output current	15 A
Output bypass	Yes
Shutdown output voltage/impedance 0 V/1 k Ω (±10%)	

Common Parameters

Technical Specifications	SUN2000-450W-P	
Dimensions (W x H x D)	71 mm x 138 mm x 25 mm	
Net weight	≤ 550 g	
DC input and output terminals	Staubli MC4	
Operating -40°C to +85°C temperature		
Storage temperature	-40°C to +70°C	
Operating humidity	0–100% RH	

Technical Specifications	SUN2000-450W-P	
Maximum operating altitude	4000 m	
IP rating	IP68	
Installation mode	PV module support installationPV module frame installation	

Long String Design (Full Optimizer Configuration)

Technical Specificati ons	SUN200 0-3KTL- M1	SUN2000- 4KTL-M1	SUN2000- 5KTL-M1	SUN2000- 6KTL-M1	SUN200 0-8KTL- M1	SUN200 0-10KTL- M1	SUN2000 -10KTL- BEM1
Minimum optimizer number per string	6						
Maximum optimizer number per string	35						
Maximum DC power per string	10,000 W						



₩ NOTE

- The grid codes are subject to change. The listed codes are for reference only.
- The SUN2000-10KTL-BEM1 supports only the Belgium grid code.

Table A-1 Grid Code

No.	Grid Code	Remarks
1	VDE-AR-N-4105	Germany low-voltage (LV) power grid
2	UTE C 15-712-1(A)	France mainland power grid
3	UTE C 15-712-1(B)	France island power grid
4	UTE C 15-712-1(C)	France island power grid
5	EN50438-CZ	Czech power grid
6	RD1699/661	Spain LV power grid
7	EN50438-NL	Netherlands power grid
8	C10/11	Belgium power grid
9	IEC61727	IEC 61727 LV grid-tied power grid (50 Hz)
10	Custom (50 Hz)	Reserved
11	Custom (60 Hz)	Reserved
12	TAI-PEA	Thailand grid-tied standard power grid
13	TAI-MEA	Thailand grid-tied standard power grid
14	EN50438-TR	Turkey LV power grid code

No.	Grid Code	Remarks	
15	IEC61727-60Hz	IEC61727 low-voltage power grid (60 Hz)	
16	EN50438_IE	Ireland LV power grid	
17	PO12.3	Spain LV power grid	
18	EN50549-LV	Ireland power grid	
19	ABNT NBR 16149	Brazil power grid	
20	DUBAI	Dubai LV power grid	
21	TAIPOWER	Taiwan Power LV power grid	
22	EN50438-SE	Sweden LV power grid	
23	Austria	Austria power grid	
24	G98	UK G98 power grid	
25	G99-TYPEA-LV	UK G99_TypeA_LV power grid	
26	SINGAPORE	Singapore LV power grid	
27	HONGKONG	Hong Kong LV power grid	
28	EN50549-SE	Sweden LV power grid	
29	AUSTRALIA-AS4777_A-LV230	Australia power grid	
30	AUSTRALIA-AS4777_B-LV230	Australia power grid	
31	AUSTRALIA-AS4777_C-LV230	Australia power grid	
32	AUSTRALIA-AS4777_NZ-LV230	Australia power grid	
33	EN50549-PL	Poland	
34	CEI0-21	Italy LV power grid	
35	SWITZERLAND-NA/EEA:2020- LV230	Switzerland	
36	DENMARK-EN50549-DK1-LV230	Denmark power grid	
37	DENMARK-EN50549-DK2-LV230	Denmark power grid	
38	Pakistan	Pakistan	
39	OMAN	Oman low-voltage power grid	
40	CZECH-EN50549-LV230	Czech power grid	
41	FINLAND-EN50549-LV230	Finland power grid	
42	ANRE	Romania low-voltage power grid	
43	Israel	Israel power grid	

No.	Grid Code	Remarks
44	Philippines	Philippines low-voltage power grid
45	NEW CALEDONIA-LV230	New Caledonia power grid
46	FRANCE-EN50549-230	France FD C11-519-11
47	NTS	Spain power grid
48	NC2022	New Caledonia power grid

B Connecting to the Inverter on the App

NOTICE

- When directly connecting your phone to a device, ensure that your phone is within the WLAN coverage of the device.
- When connecting the device to the router over WLAN, ensure that the device is within the WLAN coverage of the router and the signal is stable and good.
- The router supports WLAN (IEEE 802.11 b/g/n, 2.4 GHz) and the WLAN signal reaches the inverter.
- The WPA, WPA2, or WPA/WPA2 encryption mode is recommended for routers.
 The Enterprise mode is not supported (such as airport WLAN and other public hotspots that require authentication). WEP and WPA TKIP are not recommended because they have serious security vulnerabilities. If the access fails in WEP mode, log in to the router and change the encryption mode of the router to WPA2 or WPA/WPA2.

Step 1 Start device commissioning.





Figure B-1 Method 1: mobile phone connected to the Internet

Figure B-2 Method 2: mobile phone not connected to the Internet



Ⅲ NOTE

Method 2 can be used only when no Internet access is available. You are advised to log in to the FusionSolar app to commission devices using method 1.

Step 2 Connect to the inverter WLAN.

Tap **Scan**. On the QR code scanning screen, align the QR code with the scanning box to automatically scan and connect to the WLAN of the inverter.

□ NOTE

- The WLAN name of a product consists of "Device name-Product SN." (The last six digits of the WLAN name of some products are the same as the last six digits of the product SN.)
- Use the initial password for the first connection. You can obtain the initial WLAN password from the label on the device.
- Ensure account security by changing the password periodically. Your password might be stolen or cracked if it is left unchanged for extended periods. If a password is lost, the device cannot be accessed. In these cases, the Company shall not be liable for any loss.
- If the login screen is not displayed after you scan the QR code, check whether your phone is correctly connected to the device WLAN. If not, manually select and connect to the WLAN.
- If the message **This WLAN network has no Internet access. Connect anyway?** is displayed when you connect to the built-in WLAN, tap **CONNECT**. Otherwise, you cannot log in to the system. The actual UI and messages may vary with mobile phones.

Step 3 Log in to the device commissioning screen as **Installer**.

NOTICE

- After completing the deployment settings, the installer should remind the owner to access the local commissioning screen of the device and set the login password of the owner account as prompted.
- Ensure account security by changing the password periodically. Your password
 might be stolen or cracked if it is left unchanged for extended periods. If a
 password is lost, the device cannot be accessed. In these cases, the Company
 shall not be liable for any loss.

----End

C Connecting to the SmartAssistant on the App

NOTICE

- When directly connecting your phone to a device, ensure that your phone is within the WLAN coverage of the device.
- When connecting the device to the router over WLAN, ensure that the device is within the WLAN coverage of the router and the signal is stable and good.
- The router supports WLAN (IEEE 802.11 b/g/n, 2.4 GHz) and the WLAN signal reaches the inverter.
- The WPA, WPA2, or WPA/WPA2 encryption mode is recommended for routers.
 The Enterprise mode is not supported (such as airport WLAN and other public hotspots that require authentication). WEP and WPA TKIP are not recommended because they have serious security vulnerabilities. If the access fails in WEP mode, log in to the router and change the encryption mode of the router to WPA2 or WPA/WPA2.

Step 1 Start device commissioning.





Figure C-1 Method 1: mobile phone connected to the Internet

Figure C-2 Method 2: mobile phone not connected to the Internet



Method 2 can be used only when no Internet access is available. You are advised to log in to the FusionSolar app to commission devices using method 1.

Step 2 Connect to the WLAN of the SmartAssistant.

Tap **Scan**. On the QR code scanning screen, align the QR code with the scanning box to automatically scan and connect to the WLAN of the SmartAssistant.

□ NOTE

- SmartAssistant networking: Scan the WLAN QR code of the SmartAssistant.
- SmartGuard networking: Scan the WLAN QR code of the SmartGuard or SmartAssistant.

□ NOTE

- The WLAN name of a product consists of "Device name-Product SN." (The last six digits of the WLAN name of some products are the same as the last six digits of the product SN.)
- For the first connection, log in with the initial password. You can obtain the initial WLAN password from the label on the device.
- Ensure account security by changing the password periodically. Your password might be stolen or cracked if it is left unchanged for extended periods. If a password is lost, the device cannot be accessed. In these cases, the Company shall not be liable for any loss.
- If the login screen is not displayed after you scan the QR code, check whether your phone is correctly connected to the device WLAN. If not, manually select and connect to the WLAN.
- If the message This WLAN network has no Internet access. Connect anyway? is
 displayed when you connect to the built-in WLAN, tap CONNECT. Otherwise, you
 cannot log in to the system. The actual UI and messages may vary with mobile phones.

Step 3 Log in to the device commissioning screen as **Installer**.

NOTICE

- After completing the deployment settings, the installer shall remind the owner to access the local commissioning screen of the device and set the login password of the owner account as prompted.
- To ensure account security, protect the password by changing it periodically, and keep it secure. Your password might be stolen or cracked if it is left unchanged for extended periods. If a password is lost, devices cannot be accessed. In these cases, the Company shall not be liable for any loss.

----End

Resetting Password

- **Step 1** Check that the AC and DC sides of the inverter are both powered on, and indicators and → are steady green or blinking slowly for more than 3 minutes.
- **Step 2** Complete the following operations within 4 minutes:

Turn off the AC switch and set **DC SWITCH** to **OFF** at the bottom of the inverter. If the inverter is connected to a battery, turn off the battery switch. Wait until all LED indicators on the inverter panel turn off.

Turn on the AC switch and set **DC SWITCH** to **ON**. Wait about 90s and check that indicator r is blinking green slowly.

Turn off the AC switch and set **DC SWITCH** to **OFF**. Wait until all LED indicators on the inverter panel turn off.

Turn on the AC switch and set **DC SWITCH** to **ON**. Wait until all LED indicators on the inverter panel blink and then turn off after 30s.

- **Step 3** Reset the password within 10 minutes. (If no operation is performed within 10 minutes, all parameters of the inverter remain unchanged.)
 - 1. Wait until indicator → blinks green slowly.
 - 2. Connect to the app using the initial WLAN hotspot name (SSID) and initial password (PSW), which can be obtained from the label on the side of the inverter.
 - 3. On the login screen, set a new password and log in to the app.
- **Step 4** Set router and management system parameters to implement remote management.

----End

ERapid Shutdown

■ NOTE

The rapid shutdown function is supported only if optimizers are configured for all PV modules.

When all PV modules connected to the solar inverter are configured with optimizers, the PV system shuts down quickly and reduces the output voltage of the PV string to below 30 V within 30 seconds.

Perform the following step to trigger rapid shutdown:

- Method 1: To enable the rapid shutdown function, you need to connect the
 access switch to pins 13 and 15 of the SUN2000 communications terminal.
 The switch is closed by default. The rapid shutdown is triggered when the
 switch changes from closed to open.
- Method 2: Turn off the AC switch between the solar inverter and the power grid. (If the inverter supports the off-grid function and Off-grid mode is enabled by choosing Settings > Feature parameters on the home screen, turning off the AC switch will not trigger a rapid shutdown.)
- Method 3: Set the DC switch at the bottom of the SUN2000 to OFF. (Turning off an extra switch on the DC side of the SUN2000 will not trigger rapid shutdown. The PV string may be energized.)
- Method 4: If **AFCI** is enabled, the inverter automatically detects arc faults, triggering a rapid shutdown.

Acronyms and Abbreviations

L

LED light emitting diode

Μ

MPP maximum power point

MPPT maximum power point

tracking

Ρ

PV photovoltaic