



ⓈGND	N	L1	L2	L3	EVSE
PE	N	L1	L2	L3	TN/TT 400V
PE	N	L1			TN/TT 230V
PE	L1	L3			IT 230V



Need help?
support.volttime.com

[volttime.com/
manuals](https://volttime.com/manuals)